



Instruction Manual

Model 2407A
Mini-Pro® Digital Multimeter

Limited one-Year Warranty

B&K Precision Corp. warrants to the original purchaser that its product and the component parts thereof, will be free from defects in workmanship and materials for a period of one year from the date of purchase.

B&K Precision Corp. will, without charge, repair or replace, at its' option, defective product or component parts. Returned product must be accompanied by proof of the purchase date in the form a sales receipt. To obtain warranty coverage in the U.S.A., this product must be registered by completing and mailing the enclosed warranty card to B&K Precision Corp., 1031 Segovia Circle, Placentia, CA 92870 within fifteen (15) days from proof of purchase.

Exclusions: This warranty does not apply in the event of misuse or abuse of the product or as a result of unauthorized alternations or repairs. It is void if the serial number is alternated, defaced or removed.

B&K Precision Corp. shall not be liable for any consequential damages, including without limitation damages resulting from loss of use. Some states do not allow limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives you specific rights and you may have other rights, which vary from state-to-state.

SAFETY INFORMATION

The following safety information must be observed to insure maximum personal safety during the operation of this meter:

Always inspect your meter, test leads and accessories for any sign of damage or abnormality before every use. If any abnormal conditions exist (eg-broken test leads, cracked cases, display not reading, etc.), do not attempt to take any measurements. Do not expose the instrument to direct sun light, extreme temperature or moisture.

Never ground yourself when taking electrical measurements. Do not touch exposed metal pipes, outlets, fixtures, etc., which might be at ground potential. Keep your body isolated from ground by using dry clothing, rubber shoes, rubber mats, or any approved insulating material.

To avoid electric shock use CAUTION when working with voltages above 40Vdc or 20Vac. Never exceed the maximum allowable input value of any function when taking a measurement. Refer to the specification for maximum inputs. Never touch exposed wiring, connections or any live circuit when attempting to take measurements.

When Using the probes, keep your fingers behind the finger guards on the probes.

Measuring voltage which exceeds the limits of the multimeter may damage the meter and expose the operator to a shock hazard. Always recognize the meter voltage limits as stated on the front of the meter.

SPECIFICATIONS

Display: 3½ digit liquid crystal display (LCD) with a maximum reading of 3200.

Analog bar graph: 34 segments with measurements 12 times per second.

Polarity: Automatic, (-) negative polarity indication.

Overrange: "OL" mark indication.

Low battery indication: The "⎓" is displayed when the battery voltage drops below the operating level.

Auto power off: Meter automatically shuts down after approx. 10 minutes of inactivity.

Measurement rate: 2 times per second.

Operating environment: 0°C to 50°C at < 70% R.H.

Storage temperature: -20°C to 60°C, 0 to 80% R.H. with battery removed from meter.

Accuracy: Stated accuracy at 23°C ±5°C, <75% relative humidity.

Temperature coefficient: $0.1 \times (\text{specified accuracy}) / \text{per } ^\circ\text{C}$ (0°C to 18°C, 28°C to 50°C).

Altitude: 6561.7 Feet (2000M).

Power: Single standard 9-volt battery, NEDA 1604, JIS 006P, IEC 6F22.

Battery life: 500 hours typical with carbon-zinc.

Dimensions (H)×(W)×(D): 143mm× 68mm× 47mm(5.63×2.68×1.85 inches).

Weight: Approx. 206g(7.27oz) including battery.

Accessories: One pair test leads, 9V battery (installed) and Operating Instructions.

Range	DC Accuracy	AC Accuracy	Input impedance	Maximum input
Voltage				
320mV	±1.2% rdg. ±1d	N/A	≥1000MΩ	600VDC or
3.2V	±0.5% rdg. ±1d	±2.0% rdg. ±4d	11MΩ	600VAC rms
32V	±1.2% rdg. ±1d	±2.0% rdg. ±4d	10MΩ	
320V				
600V				
Range	DC Accuracy	AC Accuracy	Voltage burden	Legal protection
Current				
320μA	±2.0% rdg. ±1d	±2.5% rdg. ±4d	0.2V	0.5A 250V fuse
3.2mA		(50 - 200Hz)	2V	
32mA			2V	
320mA				
10A	±3.0% rdg. ±3d	±3.5% rdg. ±4d	2V	10A 600V fuse
Range	Resistance	Accuracy	Test current	Legal protection
320Ω	100MΩ	±2.0% rdg. ±3d	0.7mA	
3.2kΩ	1Ω	±1.5% rdg. ±3d	0.13mA	500VDC or
32kΩ	10Ω	±1.5% rdg. ±3d	13μA	500VAC rms
320kΩ	1kΩ	±2.5% rdg. ±3d	0.13mA	
3.2MΩ	10kΩ	±5.0% rdg. ±5d		
30MΩ				
Diode Test	1mV	±10% rdg. ±2d	0.5mA (Vf = 0.6V)	500V DC or AC rms
Continuity		Audio indication	Test current	Legal protection
Check		approx. 20Ω	0.7mA	300V DC or AC rms

OPERATION

Before taking any measurements, read the Safety Information Section. Always examine the instrument for damage, contamination (excessive dirt, grease, etc.) and defects. Examine the test leads for cracked or frayed insulation. If any abnormal conditions exist do not attempt to make any measurements.

Manually Selecting a Range

In manual range, you select and lock the meter in a range. To manually select a range:

Press [RANGE] button to hold the selected range. Subsequently pressing the [RANGE] button will select each range in sequence from the lowest to highest range. Hold the button for 2 seconds to return to the Autorange Mode.

Hold Button

Press(HOLD) button to toggle in and out of the Data Hold mode. In the Data Hold mode, the "HOLD" annunciator is displayed and the last reading is frozen on the display. Press the (HOLD) button again to exit and resume readings.

Mode Switch A

Press this switch  to toggle between DC and AC in the current measurements.

Mode Switch

If the function switch is set to  position, Press this switch to toggle between the continuity/diode modes.

Voltage Measurements

1. Connect the red test lead to the "V Ω " jack and the black test lead to the "COM" jack.
2. Set the Function switch to the desired voltage type (V $\overline{\sim}$ or V $\sim$) position.
3. Touch the probes to the test points, the range will change automatically to the level that will display the input voltage with best resolution.
4. The value indicated in the display window is the measured value of voltage with proper decimal point and annunciator indication.
5. For dc, a (-) sign is displayed for negative polarity; positive polarity is implied.

Current Measurements

1. Set the Function switch to the desired current range (μ A, mA or 10A) position.
2. To toggle between "DC" and "AC" mode, press Mode switch. The "DC" or "AC" annunciators is displayed in the upper left corner.
3. For current measurements less than 320mA, connect the red test lead to the μ A/mA jack and the black test lead to the COM jack.
4. For current measurements of 320mA to 10A, connect the red test lead to the 10A jack and the black test lead to the COM jack.
5. Remove power from the circuit under test and open the normal circuit path where the measurement is to be taken. Connect the meter in series with the circuit.
6. Apply power and read the value of the display.

Resistance Measurements

1. Set the Function switch to the " Ω " position.
2. Turn off power to the circuit under test. External voltage across the components causes invalid readings.
3. Connect the red test lead to the "V Ω " jack and the black test lead to the "COM" jack.
4. Connect the test leads to the point of measurements and read the value from the display.

Testing Diodes

1. Set the Function switch to $\rightarrow/\leftarrow$ position.
2. Turn off power to the circuit under test. External voltage across the components causes invalid readings.
3. To toggle between the continuity/diode modes, press Mode Switch.
4. Touch probes to the diode. A forward-voltage drop is about 0.6V (typical for a silicon diode).
5. Reverse probes. If the diode is good, "OL" is displayed. If the diode is shorted, a value near 0mV will be displayed.
6. If the diode is open, "OL" is displayed in both directions.

Continuity Measurements

1. Set the Function switch to $\rightarrow/\leftarrow$ position.
2. Turn off power to the circuit under test. External voltage across the components causes invalid readings.
3. To toggle between the continuity/diode modes, press Mode Switch.
4. Connect the test leads to the two points at which continuity is to be tested. The buzzer will sound if the resistance is less than approximately 20 Ω .

MAINTENANCE

Maintenance consists of periodic cleaning and battery replacement. The exterior of the instrument can be cleaned with a dry clean cloth to remove any oil, grease or grime. Never use liquid solvents or detergents.

Repairs or servicing not covered in this manual should only be performed by qualified personnel.

Battery Replacement

WARNING

TO AVOID ELECTRICAL SHOCK, DISCONNECT THE TEST LEADS AND ANY INPUT SIGNALS BEFORE REPLACING THE BATTERY. REPLACE ONLY WITH SAME TYPE OF BATTERY. (9-Volt)

This meter is powered by a NEDA type 1604 or equivalent 9-volt battery. When the meter displays the "BAT" battery must be replaced to maintain proper operation. To replace the battery, remove the three screws from the back of the meter and open the bottom case, remove the battery from battery room.

Fuse Replacement

If no current measurements are possible, check for a blow overload protection fuse. There are two fuses, F1 for the μ A/mA jack and F2 for the 10A jack. For access to fuse remove the three screws from the back of the meter and open the bottom case. Replace F1 only with the original type 0.5A/250V, fast acting fuse. Replace F2 only with the original type 10A/600V, fast acting ceramic fuse.

NOTE

The instrument complies with class II, overvoltage CAT. III of the IEC1010-1 (EN61010-1) standard. Pollution degree 2 in accordance with IEC-664 in foot use. If the equipment is used in a manner not specified, the protection provided by the equipment may be impaired.

  When servicing, use only specified replacement parts or equivalent.

The symbols used on this instrument are:

-  Caution, risk of electric shock
-  Caution, refer to accompanying documents
-  Equipment protected throughout by Double insulation (Class II)
-  Alternating current
-  Direct current
-  Ground

CE

This product complies with the requirements of the following European Community Directives: 89/336/EEC (Electromagnetic Compatibility) and 73/23/EEC (Low Voltage) as amended by 93/68/EEC (CE Marking).

However, electrical noise or intense electromagnetic fields in the vicinity of the equipment may disturb the measurement circuit. Measuring instruments will also respond to unwanted signals that may be present within the measurement circuit. Users should exercise care and take appropriate precautions to avoid misleading results when making measurements in the presence of electromagnetic interference.

Service Information

Warranty Service: Please return the product in the original packaging with proof of purchase to the below address. Clearly state in writing the performance problem and return any leads, connectors and accessories that you are using with the device.

Non-Warranty Service: Return the product in the original packaging to the below address. Clearly state in writing the performance problem and return any leads, connectors and accessories that you are using with the device. Customers not on open account must include payment in the form of a money order or credit card. For the most current repair charges contact the factory before shipping the product.

Return all merchandise to B&K Precision Corp. with pre-paid shipping. The flat-rate repair charge includes return shipping to locations in North America. For overnight shipments and non-North America shipping fees contact: B&K Precision Corp.

1031 Segovia Circle / Placentia, CA 92870
Phone: 714-237-9220 / Fax: 714-237-9214
Website: www.bkprecision.com

Include with the instrument your complete return shipping address, contact name, phone number and description of problem.

BK PRECISION

1031 Segovia Circle
Placentia, CA 92870
USA

TEL: 714-237-9220

FAX: 714-237-9214

www.bkprecision.com

PN:480-820-9-001

Printed in Taiwan

P/N: 7000-1550