

HIOKI

IR4059

Instruction Manual

INSULATION TESTER



Read carefully before use.

Keep for future reference.

EN

Dec. 2023 Edition 1
IR4059A961-00



Contents

Introduction.....	5
Verifying Package Contents	6
Options	7
Notations	10
Safety Information	13
Operating Precautions	15
1 Overview	19
1.1 Product Overview.....	19
1.2 Names and Functions of Parts	20
2 Preparing for Measurement	25
2.1 Protector	26
2.2 Replacing Batteries or Fuse.....	27
2.3 Using the L9788-10 Test Lead with Remote Switch (Red)	31
2.4 Installing the Z3210 Wireless Adapter.....	33
3 Measurement	35
3.1 Pre-measurement Inspection	35
3.2 Auto Power Save (Power-Saving Function).....	36
3.3 Auto Backlight-off (Automatic Light-off Function).....	37
3.4 Comparator Function.....	38
Setting the Comparator.....	39
Canceling the Comparator	40
3.5 Insulation Resistance Measurement.....	41
Lock Function	42
Measuring Insulation Resistance.....	43

	Displaying 1-minute Values.....	44
	Voltage Characteristics of Measurement Terminals..	45
3.6	Discharging Function	46
3.7	Voltage Measurement	47
3.8	Low Resistance Measurement.....	48
3.9	Wireless Communications Function	50
	Using the GENNECT Cross.....	50
	Excel Direct Input Function (HID function).....	54

4 Specifications 57

4.1	General Specifications	57
4.2	Basic and Accuracy Specifications.....	59
4.3	Functionality specifications.....	67
	Power-on Options	71
4.4	Other Specifications	72

5 Maintenance and Service 73

5.1	Troubleshooting	75
	Errors and status codes.....	80

Appendix Appx.1

	Appx. 1 Measurement Principles	Appx.1
	Appx. 2 Operation Uncertainty	Appx.2

Warranty Certificate

Introduction

Thank you for choosing the Hioki IR4059 Insulation Tester. To ensure your ability to get the most out of this instrument over the long term, please read this manual carefully and keep it available for future reference.

Hereinafter, the descriptions refer to models as shown on the instrument.

The latest edition of the instruction manual

The contents of this manual are subject to change, for example as a result of product improvements or changes to specifications.

The latest edition can be downloaded from Hioki's website.
<https://www.hioki.com/global/support/download/>



Product registration

Register your product in order to receive important product information.

<https://www.hioki.com/global/support/myhioki/registration/>



Intended audience

This manual has been written for use by individuals who use the product or provide information about how to use the product. In explaining how to use the product, it assumes electrical knowledge (equivalent of the knowledge possessed by a graduate of an electrical program at a technical high school).

Verifying Package Contents

When you receive the instrument, inspect it carefully to ensure that no damage occurred during shipping. In particular, check the accessories, panel switches, and connectors. If damage is evident, or if it fails to operate according to the specifications, contact your authorized Hioki distributor or reseller. Confirm that these contents are provided.

- IR4059 Insulation Tester
- L4930 Connection Cable Set
- L4935 Alligator Clip Set
- L4938 Test Pin Set
- L9788-10 Test Lead with Remote Switch (Red)
- Z5042 Protector
- Neck strap
- LR6 Alkaline battery ×4
- Instruction Manual
- Operating Precautions (0990A907)

Options

The options listed below are available for the instrument. To order an option, please contact your authorized Hioki distributor or reseller.


Options are subject to change. Please check Hioki's website for the latest information.

Model	Maximum rated voltage and maximum rated current
Z3210 Wireless Adapter 	—
L4930 Connection Cable Set (1.2 m) 	CAT IV 600 V/CAT III 1000 V 10 A
L4935 Alligator Clip Set 	CAT IV 600 V/CAT III 1000 V 10 A
L4938 Test Pin Set 	CAT III 600 V/CAT II 600 V 10 A
L9787 Test Lead (1.2 m) 	CAT III 600 V/CAT II 600 V 10 A
L9787-91 Breaker Pin 	CAT III 600 V 10 A

Options

Model	Maximum rated voltage and maximum rated current
L9788-10 Test Lead with Remote Switch (Red) 	CAT III 600 V/CAT II 600 V 2 A
L9788-11 Test Lead Set with Remote Switch 	CAT III 600 V/CAT II 600 V 2 A
L9788-90 Tip Pin 	CAT III 600 V/CAT II 600 V 2 A
L9788-92 Breaker Pin 	CAT III 600 V 2 A
9804-01 Magnetic Adapter (Red) 9804-02 Magnetic Adapter (Black) (φ11 mm, standard screw: M6 pan head screw) 	CAT IV 1000 V 2 A
Z5042 Protector 	

Test Lead



Notations

Safety notations

In this document, the severity levels of risk and hazard are classified as follows.

 DANGER	Indicates an imminently hazardous situation that will result in death or serious injury to the operator.
 WARNING	Indicates a potentially hazardous situation that may result in death or serious injury to the operator.
 CAUTION	Indicates a potentially hazardous situation that may result in minor or moderate injury to the operator or damage to the instrument or malfunction.
IMPORTANT	Indicates information or content that is particularly important from the standpoint of operating or maintaining the instrument.
	Indicates a strong magnetic-field hazard. The effects of the magnetic force can cause abnormal operation of heart pacemakers and/or medical electronics.
	Indicates prohibited actions.
	Indicates the action which must be performed.
*	Additional information is presented below.

Symbols on the instrument

 <p>Indicates cautions and hazards. When the symbol is printed on the instrument, refer to a corresponding topic in the Instruction Manual.</p>	 <p>Indicates a grounding terminal.</p>
 <p>Indicates that dangerous voltage may be present at this terminal.</p>	 <p>Indicates DC (Direct Current).</p>
 <p>Indicates an instrument that has been protected throughout by double insulation or reinforced insulation.</p>	 <p>Indicates AC (Alternating Current).</p>  > 660V  > ~ 660V <p>Do not use in distribution systems with voltage higher than 660 V AC.</p>

Symbols for various standards

	<p>Indicates the Waste Electrical and Electronic Equipment Directive (WEEE Directive) in EU member states.</p>
	<p>Indicates that the product conforms to regulations set out by the EU Directive.</p>

Screen Display

The instrument screen displays the alphanumeric characters as follows.

A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y	Z
A	b	C	d	E	F	G	H	1	2	L	ñ	o	P	q	r	S	t	U	u	y	1	4	≡		

1	2	3	4	5	6	7	8	9	0
1	2	3	4	5	6	7	8	9	0

Accuracy

Hioki expresses accuracy as error limit values specified in terms of

percentages of reading and digits.

Reading (Displayed value)	Refers to the displayed value of the measuring instrument. The limit values of reading errors are expressed in percent of reading (% of reading, % rdg).
Digits (Resolution)	Refers to the smallest change in the indication on the digital measuring instrument, i.e., the numeral one in the rightmost place. The limit values of digit errors are expressed in terms of digits (dgt).

Trademarks

- The Bluetooth[®] word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Hioki E.E. Corporation is under license. Other trademarks and trade names are those of their respective owners.
- Excel is a trademark of the Microsoft group of companies.

Safety Information

This instrument is designed to conform to IEC 61010 Safety Standards, and has been thoroughly tested for safety prior to shipment. However, using the instrument in a way not described in this manual may negate the provided safety features.

Before using the instrument, be certain to carefully read the following safety notes:

DANGER



Mishandling during use could result in injury or death, as well as damage to the instrument. Be certain that you understand the instructions and precautions in the manual before use.

WARNING



Protective gear
Performing measurement using this instrument involves live-line work. To prevent an electric shock, use appropriate protective insulation and adhere to applicable laws and regulations.

Measurement Categories

To ensure safe operation of measuring instruments, IEC 61010 establishes safety standards for various electrical environments, categorized as CAT II to CAT IV, and called measurement categories.


DANGER



- **Using a measuring instrument in an environment designated with a higher-numbered category than that for which the instrument is rated could result in a severe accident, and must be carefully avoided.**
- **Never use a measuring instrument that lacks category labeling in a CAT II to CAT IV measurement environment. Doing so could result in a serious accident.**

This instrument conforms to the safety requirements for CAT III 600 V measuring instruments.

- CAT II: When directly measuring the electrical outlet receptacles of the primary electrical circuits in equipment connected to an AC electrical outlet by a power cord (portable tools, household appliances, etc.)
- CAT III: When measuring the primary electrical circuits of heavy equipment (fixed installations) connected directly to the distribution panel, and feeders from the distribution panel to outlets.
- CAT IV: When measuring the circuit from the service drop to the service entrance, and to the power meter and primary overcurrent protection device (distribution panel).



Operating Precautions

Observe the following precautionary information to ensure that the instrument can be used safely and in a manner that allows it to perform as described in its specifications.

Use of the instrument should confirm not only to its specifications, but also to the specifications of all accessories, options, batteries, and other equipment in use.

DANGER



- For your safe operation, do not connect any test lead to the primary of the distribution panel.
- Do not short-circuit two wires to be measured by bringing the test leads into contact with them. Arcs or such grave accidents are likely to occur.
- To avoid short circuit or electric shock, do not touch the metal part of the connecting test lead tip.
- To avoid electric shock, be careful to avoid shorting live lines with the test leads tip.

If the test lead or the instrument is damaged, there is a risk of electric shock. Perform the following inspection before using them:



- Before using the instrument check that the coating of the test leads are neither ripped nor torn and that no metal parts are exposed. Using the instrument under such conditions could result in electric shock. Replace the test leads with those specified by Hioki.
- Verify that the instrument operates normally to ensure that no damage occurred during storage or shipping. If you find any damage, contact your authorized Hioki distributor or reseller.

WARNING

To avoid electric shock, short circuits and damage to the instrument, observe the following precautions:



- Check the position of the rotary switch before taking measurements.
- Disconnect the test leads from the measuring object before switching the rotary switch.



- Do not use the instrument with circuits that exceed its ratings or specifications. Doing so may damage the instrument, resulting in electric shock.



- Use only the specified test leads. Use of any test lead not specified by Hioki does not allow safe measurements.
- To prevent electrical accidents, turn off the circuit before connecting the test leads.
- To avoid electric shock, do not exceed the lower of the ratings shown on the instrument and test leads.

CAUTION



- The cable is hardened under the 0°C or colder environment. Do not bend or pull it to avoid tearing its shield or cutting cable.
- The protection rating for the enclosure of this device (based on EN 60529) is IP40*.

* IP40:

This indicates the degree of protection provided by the enclosure of the device against use in hazardous locations, entry of solid foreign objects, and the ingress of water.

- 4: Protected against access to hazardous parts with wire measuring 1.0 mm in diameter.
- 0: The equipment inside the enclosure is not protected against the harmful effects of water.

Installing the instrument

WARNING

Installing the instrument in inappropriate locations may cause a malfunction of instrument or may give rise to an accident. Avoid the following locations.



- Exposed to direct sunlight or high temperature
- Exposed to corrosive or combustible gases
- Exposed to a strong electromagnetic field or electrostatic charge
- Near induction heating systems (such as high-frequency induction heating systems and IH cooking equipment)
- Susceptible to vibration
- Exposed to water, oil, chemicals, or solvents
- Exposed to high humidity or condensation
- Exposed to high quantities of dust particles

CAUTION



Do not place the instrument on an unstable table or an inclined place. Dropping or knocking down the instrument can cause injury or damage to the instrument.

Precautions when transporting the instrument

During shipment of the instrument, handle it carefully so that it is not damaged due to a vibration or shock.

Handling the Instrument

DANGER



Persons wearing electronic medical devices such as a pacemaker should not use the 9804-01, 9804-02 Magnet Adapter. Such persons should avoid even proximity to the 9804-01 and 9804-02, as it may be dangerous. Medical device operation could be compromised, presenting a hazard to human life.

CAUTION



To avoid damage to the instrument, protect it from physical shock when transporting and handling. Be especially careful to avoid physical shock from dropping.

Test leads

CAUTION



- Removable sleeves are attached to the metal pins at the end of the test leads. To prevent a short circuit accident, be sure to use the test leads with the sleeves attached when performing measurements in the CAT III measurement category. Remove the sleeves before starting CAT II measurements. You can use the test leads with the sleeve removed for secondary side of the circuit breakers turned off. (See “Measurement Categories” (p. 14))
- If the sleeves are inadvertently removed during measurement, stop the measurement. (p.32)

1.1 Product Overview

This instrument is an insulation ohmmeter that shortens work times associated with insulation testing. It is not designed for use on manufacturing lines and should not be used in such applications. For manufacturing line applications, use the ST5520 Insulation Tester.

High-speed response

- Considerably improved response time compared to previous models.
- The instrument can be used like models with a meter needle.

Enhanced comparator function

- Can be used similarly to the continuity check with a tester due to judgment after the start of measurement being extremely short.
- The backlight lights up in red for a FAIL judgment (defective).

Low variation in measured values

- The instrument generates little variation in measured values when used in a typical measuring environment.

Easy-to-view display


- Backlight source is a white high-intensity LED.
- Wide viewing angle LCD

High-accuracy voltage measurement function

- The instrument incorporates a DC/AC voltmeter with the same accuracy as a card tester.
- There is no need to switch to a card tester when you need to measure voltage.

1.2 Names and Functions of Parts

Front



- | | |
|---------------------------------|---|
| 1 MEASURE key (p.21) | Starts insulation resistance measurement. |
| 2 EARTH terminal | Connects the black test lead. |
| 3 CONTROL terminal | Controls L9788-10 Test Lead with Remote Switch (Red) |
| 4 LINE terminal | Connects the red test lead. |
| 5 Rotary switch | Selects measurement functions. |
| 6 LIGHT key | Turns on and off the backlight. |
| 7 0Ω ADJ key | Performs zero-adjustment for the low resistance range.(p.48)
Press with the COMP key simultaneously: configures the wireless communications function. (p. 50) |
| 8 Live circuit indicator | Lights up when voltage remains between input terminals. |

9 COMP key



Sets the comparator's judgment reference value.

Press with the **0Ω ADJ** key simultaneously: configures the wireless communications function. (p. 50)

10 RELEASE key


Press before measurement to set the instrument to the 500 V or 1000 V range (to prevent erroneous application of the test signal).

MEASURE key

MEASURE key operation			
	Pull*	Press and hold right side	Fold down (or release).
Description in this manual	Turn on the MEASURE key.		Turn off the MEASURE key.

*: Convenient way for performing measurement repeatedly


Power OFF

Rotary switch status	
Description in this manual	Turn off the rotary switch.

Rear (Serial number label)

The serial number consists of nine digits. The first two indicate the year of manufacture (the last two digits of the Western year), and the next two indicate the month of manufacture.

Display



	Battery indicator (three levels) (p.35)
	Turns on when the voltage measured with the V range is DC.
	Turns on when the voltage measured with the V range is AC.
	Blinks when the measured value is less than the minimum display value.
	Blinks when the measured value is greater than the maximum display value.
HOLD	Turns on when the measured value is retained.
PASS	Turns on when the comparator judgment is PASS (good). (p.38)
FAIL	Turns on when the comparator judgment is FAIL (defective). (p.38)
	Blinks when a dangerous voltage exists between the measurement terminals.
	Judgment result buzzer (only when comparator is set) (p.38)
APS	Appears 30 s before auto power save function is activated. (p.36)
0Ω ADJ	Turns on when zero adjustment is performed during low resistance measurement. (p.48)

Displaying 1-minute values (p.44)

1min

- Turns on when 1 minute has passed since the start of insulation resistance measurement.
 - Indicates that the resistance value on the bottom of the display is a 1-minute value (the measured value 1 minute after the start of measurement).
-

COMP Turns on when the comparator function is enabled. (p.38)

Turns on when the instrument is set to the 500 V range or the 1000 V range.



Pressing  turns off the indicator and enables insulation measurement.



Indicates wireless communications function status. (p. 50)

L9788-11 Test Lead Set with Remote Switch

Model L9788-11 is a set of Model L9788-10 Test Lead with Remote Switch (red) and a test lead (black).

See “Options” (p. 7)


CAUTION



The **MEASURE** key of the instrument is enabled even when the L9788-10 is connected to an insulation resistance tester. Note that the testing voltage is output when the **MEASURE** key of the instrument is turned ON while the L9788-10 is connected.

Refer to “Attaching the L9788-92 Breaker Pin” (p. 32)

L9788-10 Test Lead with Remote Switch (optional)



1 Light

Lights up interlocked with the backlight of the instrument.

2 **MEASURE** key

- Starts insulation resistance measurement.
- Lights up in red interlocked with the live wire warning indicator of the instrument.

3 Judgment display

- Lights up in accordance with the comparator judgment result.
- PASS: Green
 - FAIL: Red

2

Preparing for Measurement

CAUTION




Attach the strap securely to the fittings on the instrument. If insecurely attached, the instrument may fall and be damaged when carrying.

1 Insert the batteries. (p.27)

2 Attach the strap.

Pass the strap through a lug-hole on the instrument.

Secure the strap at 4 positions.



3 Connect the test leads to the terminals.


EARTH terminal

Connect the black test lead.




LINE terminal

Connect the red test lead.




4 Attach each test pin or alligator clip to a lead.



2.1 Protector


Attaching the protector

Tilt the instrument and slide it into the protector, and then push the entire instrument into the protector.



Removing the protector

Hold it with both hands and push the one end of the protector down.



2.2 Replacing Batteries or Fuse

Before using the instrument for the first time, insert four LR6 Alkaline batteries or four fully charged HR6 Nickel-metal hydride batteries.

WARNING



- To avoid electric shock, turn off the **MEASURE** key, disconnect the test leads from the measuring object before replacing the battery cover.



- After replacing the batteries, reattach the cover and secure the screw before using the instrument.
- Battery may explode if mistreated. Do not shortcircuit, recharge, disassemble or dispose of in fire.
- Replace the fuse only with one of the specified type, characteristics, rated current, and rated voltage. Do not use fuses other than those specified (especially, do not use a fuse with higher-rated current) or do not short circuit and use the fuse holder. Doing so may damage the instrument and result in bodily injury.

Fuse type: FF0.5 AH/1000 V (70 172 40.0.500: SIBA GmbH) (Fast blow, arc-extinguishing material included, and high breaking capacity)

The fuses can be purchased via authorized Hioki distributor or reseller.

- To prevent instrument damage or electric shock, use only the screw for securing the battery cover in place that are originally installed. If you have lost a screw or find that a screw is damaged, please contact your authorized Hioki distributor or reseller.

CAUTION

Poor performance or damage from battery leakage could result. Observe the cautions listed below.



- Do not mix old and new batteries, or different types of batteries.
- Pay attention to the polarity markings “+” and “-”, so that you do not insert the batteries the wrong way around.
- Do not use batteries after their recommended expiry date.
- Do not leave depleted batteries inside the instrument.
- Replace batteries only with the specified type.
- Use batteries with low internal resistance.

- The battery indicator blinks when the remaining battery capacity is low. In this case, measurement is not possible. Replace the batteries with new ones. (p.35)
- Handle and dispose of batteries in accordance with local regulations.

Nickel-metal hydride batteries

CAUTION



When using the instrument, insert four LR6 Alkaline batteries or four fully charged HR6 Nickel-metal hydride batteries.

The instrument powered by nickel-metal batteries will indicate an inaccurate remaining-battery level; however, it can be used without any trouble even with such batteries inserted.

See the continuous operating time below.

Continuous operating time when LR6 Alkaline batteries are used (reference values at 23°C)

- Approx. 20 hours (without the Z3210 installed, with the comparator and backlight set to off, when making measurement using the 500 V range with the measurement terminals open-

circuited)

- Approx. 15 hours (with the Z3210 installed, in wireless communication, with the comparator and backlight set to off, when making measurement using the 500 V range with the measurement terminals open-circuited)

Continuous operating time when HR6 Nickel-metal hydride batteries are used (reference values at 23°C) (when using 1900 mAh nickel-metal hydride batteries).

- Approx. 31 hours (without the Z3210 installed, with the comparator and backlight set to off, when making measurement using the 500 V range with the measurement terminals open-circuited)
- Approx. 28 hours (with the Z3210 installed, in wireless communication, with the comparator and backlight set to off, when making measurement using the 500 V range with the measurement terminals open-circuited)

Visit an FAQ page on Hioki's global website for more information about nickel-metal hydride batteries that Hioki has guaranteed to work.

The instrument with nickel-metal hydride batteries inserted is not drop-proof.

Procedure

You will need:


- LR6 Alkaline battery ×4 or
HR6 Nickel-metal hydride battery ×4
- Phillips-head screwdriver (No. 2)



1 Turn off the rotary switch and remove the test lead from the instrument.

2 Remove the protector. (p.26)

Rear



Batteries
Check the
polarity.

Fuse
FF0.5 AH/1000 V
(70 172 40.0.500:
SIBA GmbH)

3 Loosen the fastening screw and remove the battery cover.

4 Replace all four batteries or the fuse.

5 Attach the protector. (p.26)


6 Slide the battery cover back into place and tighten the screw.

2.3 Using the L9788-10 Test Lead with Remote Switch (Red)

2

Pre-measurement inspection

- 1 Turn off the rotary switch.
- 2 Fully insert the L9788-10 plug into the **LINE** terminal of the instrument.



- 3 Set the rotary switch to insulation resistance range.

- 4 With the test lead tips shorted, press the **MEASURE** key on the L9788-10.




- 5 Check the following:

- The L9788-10's **MEASURE** key lights up red in conjunction with the live circuit indicator on the instrument.
- The indicator of the instrument indicates 0 M Ω .




- 6 Press **LIGHT**.




Check that the L9788-10 tip lamp lights up.

Replacing the Tip Pin (optional) for the L9788-10

When the tip pin of the L9788-10 Test Lead with Remote Switch (Red) (option) is worn out or broken, it can be replaced. The tip pin can be purchased via authorized Hioki distributor or reseller.



1 Turn off the rotary switch and disconnect the L9788-10.



2 Remove the tip pin by rotating with a wrench.

3 Attach the new tip pin to the L9788-10 by rotating with a wrench.

(Tightening torque: 0.3 N•m)


4 Check the operation.

Measure a measuring object of known values and use after checking that the resistance is correct.


Attaching the L9788-92 Breaker Pin

Remove the sleeve of the L9788-10 and attach the breaker pin.

Fully insert.



Removing and attaching the test lead sleeves



Safely store the removed sleeves so as not to lose them. (p. 18)

Removing the sleeves	Attaching the sleeves
Hold the bottom of the sleeves and pull the sleeves off. (For safety reasons, the cap has been manufactured to fit snugly so that it cannot be easily removed.)	Insert the metal pins of the test leads into the holes of the sleeves, and firmly push them all the way in.

2.4 Installing the Z3210 Wireless Adapter

The wireless communications function can be used by installing the Z3210 Wireless Adapter (option) to the instrument.

WARNING



- To avoid electric shock, turn off the **MEASURE** key and remove the test leads from the measuring object before removing the battery cover.



- After installing or removing the Z3210, be sure to reattach the battery cover and secure it in place with the screw before using the instrument.
- To prevent instrument damage or an electric shock, use only the screws that are originally installed for securing the battery cover in place. If you have lost any screws or find that any screws are damaged, please contact your authorized Hioki distributor or reseller.

CAUTION




After touching any metallic part, such as a doorknob, to eliminate static electricity from your body, connect or disconnect the Z3210. Failure to do so could cause static electricity to damage the Z3210.

Procedure

You will need:

- Phillips-head screwdriver (No. 2)
- Flat-head screwdriver
- Z3210 Wireless Adapter (option)

Rear



- 1** Turn off the rotary switch and remove the test leads.
- 2** Remove the protector. (p.26)
- 3** Unscrew the screws and remove the battery cover.
- 4** Remove the protective cap with a flat-head screwdriver.
- 5** Exercising care to orient the Z3210 correctly, install the Z3210 as far as it will go.
- 6** Reattach the battery cover and tighten the screws.
- 7** Attach the protector. (p.26)


3

Measurement


3.1 Pre-measurement Inspection

Before using the instrument, verify that it operates normally to ensure that no damage occurred during storage or shipping. If you find any damage, contact your authorized Hioki distributor or reseller.

Checking the remaining battery charge



Checking the test lead



Inspection complete

Please read the “Operating Precautions” (p. 15) before use.


3.2 Auto Power Save (Power-Saving Function)

When the rotary switch is not in the OFF position, the instrument changes to the auto power save state approx. 10 minutes after the last operation or live wire warning indication.

To avoid battery depletion, turn off the rotary switch after use (the auto power save consumes a small amount of current).

Canceling the auto power save

Other than the OFF position.



Turn on the instrument while holding down ^{LIGHT} .

Recovering from auto power save state

Set the rotary switch to OFF and then return it to its original position.


3.3 Auto Backlight-off (Automatic Light-off Function)

The backlight of the instrument will automatically turn off after approx. 3 minutes has passed since the last operation.

The automatic light-off function can be canceled when working continuously in a dark location.

Canceling the automatic light-off function

Backlight: OFF



Press for approx. 2 seconds.

Set the rotary switch to any position other than OFF.
With the backlight off, press 
for approx. 2 seconds until the instrument beeps.

The automatic light-off function is enabled by setting the rotary switch to OFF.

3.4 Comparator Function

This function compares the measured value with the preset value and judges whether the result is PASS (good) or FAIL (defective).

Comparator settings for each range will be saved, even if the rotary switch is turned off.

See the table on the next page for criteria that can be set.

Indication lights up

	PASS (good) judgment		FAIL (defective) judgment	
LED display				
	Backlight: No change	Lights up in green*	Backlight: Lights up in red	Lights up in red*

* When using the L9788-10 Test Lead with Remote Switch (Red)

Type of measurements that can be judged

Function	PASS judgment		FAIL judgment	
	State of measured value	Buzzer	Backlight	Buzzer
Insulation Resistance	Criterion or higher	Short beep	Lights up in red	Long beep
Low resistance	Criterion or lower	Long beep		Short beep
Voltage	Comparator cannot be set.			

Setting the Comparator


1 Select a judgment reference from the table below.

Range	Reference value						Unit
50 V	0.01	0.02	0.03	0.04	0.05	–	MΩ
	0.1	0.2	0.3	0.4	0.5	–	
	1* ¹	2	3	4	5	–	
	10	–	–	–	–	Off	
125 V	0.1	0.2	0.3	0.4	0.5	–	
	1* ¹	2	3	4	5	–	
	10	20	–	–	–	Off	
250 V	0.1	0.2	0.3	0.4	0.5	–	
	1* ¹	2	3	4	5	–	
	10	20	30	40	50	Off	
500 V	0.1	0.2	0.3	0.4	0.5	–	
	1* ¹	2	3	4	5	–	
	10	20	30	40	50	–	
	100	–	–	–	–	Off	
1000 V	0.1	0.2	0.3	0.4	0.5	–	
	1	2	3	4	5	–	
	10* ¹	20	30	40	50	–	
	100	200	300	400	500	Off	
Ω	0.1	0.2	0.3	0.4	0.5	0.6	Ω
	1	2	3	4	5	6	
	10	20* ¹	30	40	50	60	
	100	200	–	–	–	Off	

*1: Factory default setting

- 2** Set the rotary switch to the range for which you wish to set the judgement reference.

Range	Operation
500 V 1000 V	Press  to release the lock.




- 3** Press .

[COMP] blinks and the resistance value that will be used as the judgement reference is displayed.

- 4** Press  or  to select the judgement reference. (p.39)

If there is no operation for about 2 seconds after you select the judgment reference, the comparator will be set, and [COMP] will light up.

Canceling the Comparator



- Press  several times to select [OFF].

If there is no operation for for about 2 seconds after you select, [COMP] will go off, and the comparator function will be canceled.

3.5 Insulation Resistance Measurement

The instrument is used to measure the insulation resistance to determine the insulation performance of circuits and equipment. Before starting a measurement, the voltage to be applied to the measuring object needs to be selected.

WARNING

Observe the following to avoid electric shock, short circuit, or damage to the instrument.

- **Do not attempt to measure insulation resistance on a live conductor. Doing so could damage the instrument or cause an accident that might result in injury or death. Always turn off power to the measuring object before starting.**
- **When measuring insulation resistance, dangerous voltage is applied to the measurement terminals. To avoid electric shock, do not touch the metal part of the test leads.**
- **Do not touch the measuring object immediately after measurement. Doing so may cause electric shock due to a highly charged voltage.**
- **Discharge the measuring object with the discharge function of the instrument after a measurement. (p.46)**




- Insulation resistance is the ratio of applied voltage to leakage current. Displayed value may not stabilize depending on the measuring object, but it is not a failure of the instrument.
- Press the **MEASURE** key fully down until a live circuit indicator lights up. If the button is not pressed down fully, a proper measurement cannot be made.
- Turn off the rotary switch after use.
- Disconnection when measuring is recommended of any equipment having a lower withstanding voltage than the test voltage, or equipment or parts having an unknown withstanding voltage connected to the circuit to be measured.


Lock Function

This function is used to avoid applying high voltage such as 500 V or 1000 V to equipment having a lower withstanding voltage. This function will prevent the test voltage from being output even if the **MEASURE** key is pressed while the rotary switch is set to the 500 V or 1000 V range.

Releasing the lock



- 1 Set the rotary switch to the 500 V or 1000 V range.



- 2 Press  .
Pressing this key unlocks the instrument and switches to the measurement screen.

The screen is locked 1 minute after the last measurement or operation again.

Measuring Insulation Resistance


⚠ CAUTION



To avoid electric shock, turn off the measuring line breaker.

Example: When measuring the insulation resistance between the circuit and the ground

1 OFF




1 Turn off the **MEASURE** key.

2 Set the rotary switch to a test voltage of 50 V to 1000 V.

In the 500 V or 1000 V range, press  to release the lock. (p.42)

3



3 Connect the black test lead to the ground side of the object being measured.

4 Connect the red test lead to the measuring object.

If there is any remaining voltage on the measuring object, red and white blink alternately on the backlight.

5 Press and hold the **MEASURE** key.

To make continuous measurements, pull up the **MEASURE** key. (p.21)
Do not touch the metal part (tip), on which a dangerous voltage is present during measurement, of the test lead.

6 Check the value after the indicator has stabilized.

7 Turn off the MEASURE key with the test leads connected to the measuring object.

The last measured values and **HOLD** are displayed and starts discharging. (p.46)

- Do not switch the function to other function or rated voltage when the measurement is in progress.
- The instrument will return to the locked state when about 1 minute of no operation elapses during measurement in the 500 V and 1000 V ranges. To continue measurement, release the lock. (p.42)

Displaying 1-minute Values

The function cannot be used if the comparator function has been enabled. Disable the comparator function before use. (p. 40)


This function automatically retains the measured value (1-minute value) 1 minute after the start of measurement (after the **MEASURE** key is turned on). Use this function when measuring a object such as a cable that includes a capacitance component.



Retained measured value

- No value is shown if less than 1 minute has elapsed since the start of measurement.

Voltage Characteristics of Measurement Terminals




3.6 Discharging Function

After measurements are completed, discharge the measuring object. When objects with capacitance component are measured, a charge equivalent to the rated measurement voltage remains in the object that may cause electric shock.

When measuring a solar panel, ⚡ mark may not disappear since the instrument will continue to detect the panel's voltage once discharging ends.



Without removing the test leads from the measuring object, turn off the **MEASURE** key.



Discharging

The built-in discharge resistor automatically discharges the item.

The bar graph level decreases according to discharge. However, measuring objects with smaller capacitance component discharge quickly and the bar graph level may not change.



Discharged

When the discharge is completed, ⚡ mark is turned off.


The time required for discharge depends on the capacitance value.

3.7 Voltage Measurement

This instrument can measure the AC voltage and DC voltage of commercial power. The instrument can check to ensure that the measuring object is not live before measuring insulation resistance.

- During measuring, do not switchover to other functions.
- For waveforms other than sine waves, some errors may occur.
- Displayed values can frequently fluctuate due to induction potential even when no voltage is applied. This, however, is not a malfunction.

Example: When measuring the voltage between the circuit and ground



- 1** Set the rotary switch to V.
- 2** Connect the black test lead to the earth side of the object being measured.
- 3** Connect the red test lead to the line side of the breaker.
- 4** Check the value after the indicator has stabilized.

3.8 Low Resistance Measurement

WARNING



Do not measure under a live circuit condition.

CAUTION



- If active circuits are connected to the measuring object circuit in parallel, the impedance and transient current of the parallel circuit could cause measurement errors.
- Auto range selection may not operate in a stable manner depending on the measuring object (for example, a motor, transformer, or coil).
- The instrument may not be able to obtain an accurate measured value if there is a capacitance component in parallel with the measuring object.

The comparator function can be used during low resistance measurement. See “3.4 Comparator Function” (p. 38)


For accurate measurements, be sure to perform zero adjustment before measuring, to cancel the wire resistance of the test leads.

Zero adjustment can be performed with readings of up to a maximum of 3 Ω . When the reading exceeds 3 Ω , [Err 1] or [Err 0 Ω ADJ] will be displayed, and zero adjustment will not be possible. Wire the instrument so that the wiring resistance is 3 Ω or less.


In the following circumstances, repeat the zero adjustment procedure:

- After changing test leads
- When the ambient temperature changes by 1°C or more
- After replacing the fuse

Example: Checking continuity of grounding wire



- 1 Set the rotary switch to the Ω .
- 2 Short circuit the tip of the test lead.
- 3 Turn on the **MEASURE** key.
- 4 Turn off the **MEASURE** key to retain the measured value.
- 5 Press 0.0 ADJ.



- 6 Connect the test lead to the measuring object.
- 7 Press and hold the **MEASURE** key to check the displayed value.
To make continuous measurements, pull up the **MEASURE** key.
- 8 Turn off the **MEASURE** key after measurement.


3.9 Wireless Communications Function

Using the GENNECT Cross


This function cannot be used at the same time as the HID function. (p.54)

When the wireless communications function is enabled, you can review measurement data and create measurement reports on mobile devices. For details, see the Help function in the GENNECT Cross (application software, free of charge).

- 1 Install the **Z3210 Wireless Adapter (option)** to the instrument. (p.33)
- 2 Install the **GENNECT Cross** on your mobile device.
- 3 Turn on the instrument to enable the wireless communications function.



Blinks: Communicating



Press and hold the two keys for at least 1 s.


- 4 Launch the **GENNECT Cross** and pair it with the instrument. (p.51)
- 5 Select the standard measurement function and start measurement.




- The communication distance is approx. 10 m (line of sight). The distance over which data can be sent and received varies greatly depending on whether there are any obstructions between the paired instruments (for example, walls, metal barriers, etc.) and

- on the distance between the instrument and the floor (or ground). To ensure stable communication, verify adequate signal strength.
- Although the GENNECT Cross is provided free of charge, downloading or using the application software may incur Internet connection charges. Such charges are the sole responsibility of the user.
 - The GENNECT Cross is not guaranteed to operate on all mobile devices.
 - The Z3210 uses 2.4 GHz band wireless technology. It may not be possible for the device to establish a wireless connection when used in the vicinity of other devices that use the same frequency band, for example Wi-Fi devices (IEEE 802.11.b/g/n).

Pairing the App



- When the app is launched for the first time (before being paired with any instrument), the connection setup screen will be displayed.
- While the mobile device is displaying the connection setup screen, simply move it close to the the instrument to automatically pair it with the instrument (the app can be paired with up to 8 instruments).
- Allow about 5 to 30 seconds for the instrument to pair with the app after being turned on. If the instrument fails to pair within 1 minute, relaunch GENNECT Cross and cycle the instrument's power.
- Instruments that have been registered do not require to be registered again.




Making Measurements with the Wireless Communications Function

On the home screen, select the standard measurement function from the options, standard measurement, logging and waveform display, to start a measurement. For more information about each function, see the help function in the GENNECT Cross.

The values displayed by the instrument may be different from the values displayed by the application software due to communication delays or differences in the update timing.

Standard measurement

Measured values of multiple channels are saved.



Excel Direct Input Function (HID function)

This function cannot be used at the same time as GENNECT Cross (p.50).

The human interface device (HID) profile, with which the Z3210 Wireless Adapter is equipped, is a profile same as that wireless keyboards use.

HID ON	Preparatory to data entry, open an Excel file on your mobile device or computer and choose a cell. Freezing the instrument's display can enter the measured values on the cells.
HID OFF	Select this setting when using GENNECT Cross.

The setting whether the HID function has been enabled or disabled will not be saved in the instrument but in the Z3210.



Measured value input method

Insulation resistance, low resistance:

Press and release the **MEASURE** key.

Voltage: Press the **MEASURE** key.

Checking and changing the HID setting

- 1 Set the rotary switch to OFF.
- 2 Install the Z3210 Wireless Adapter (option) to the instrument.


See “2.4 Installing the Z3210 Wireless Adapter” (p. 33)

If the wireless communications function is off, you won't be able to check or change the HID setting. Enable the wireless communications function first before attempting to check or change the HID setting (Step 3 on p. 50).

- 3 Check the HID setting.

Turn on the instrument while holding down the **RELEASE** key to display the serial number screen.

Press and hold the **RELEASE** key for at least 3 s to display the HID setting saved by the Z3210.



To leave the HID setting unchanged

Set the rotary switch to OFF.

To change the HID setting

Proceed to Step 4.

If the instrument beeps and the display doesn't change

Using GENNECT Cross (Ver. 1.8 or later), update the Z3210 to the latest version.

- 4 Change the HID setting.

Toggle the HID setting on and off by pressing the **0 Ω ADJ** key or the **COMP** key.

- 5 Accept the setting

Press the **RELEASE** key to accept the HID setting. The instrument will automatically turn off.

IMPORTANT

To switch from the HID function to GENNECT Cross

If you launch GENNECT Cross without unpairing the mobile phone and the instrument, the application may fail to recognize the instrument as a connected device.

Reconnect the instrument to GENNECT Cross as follows:

1. Delete the instrument from your device's **Bluetooth**[®] settings.
2. Turn off the Z3210's HID function. (p.55)
3. Reconnect the instrument using GENNECT Cross's connected device settings.

For details, please check the Z3210's website.

<https://z3210.gennect.net>




▲
Learn more here!

4

Specifications

4.1 General Specifications

Operating environment	Indoors, Pollution Degree 2, altitude up to 2000 m (6562 ft.)
Operating temperature and humidity	-25°C to 40°C (-13°F to 104°F), 90% RH or less (no condensation) 40°C to 65°C (104°F to 149°F), at 65°C and below relative with linear decrease up to 25% RH (no condensation)



Storage temperature and humidity	-25°C to 65°C (-13°F to 149°F), 90% RH or less (no condensation)
---	--

Dustproof and waterproof	IP40 (EN 60529)
---------------------------------	-----------------

Drop proof	On concrete: 1 m
-------------------	------------------

Standards	EMC: EN 61326 Safety: EN 61010 EN 61557-1 EN 61557-2 EN 61557-4* ¹ EN 61557-10
------------------	--

*1: Subclause 4.3 of Part 4 (Interchanging of test leads) is not applicable when model L9788-10 is used.

Power supply	<ul style="list-style-type: none">• LR6 Alkaline battery ×4 Rated supply voltage: 1.5 V DC ×4• HR6 Nickel-metal hydride battery ×4 Rated supply voltage: 1.2 V DC ×4 Maximum rated power: 3 VA
Continuous operating time When using four LR6 Alkaline batteries (reference value at 23°C)	Approx. 20 hours (without Z3210 installed, comparator off, backlight off, measured with measurement terminal open at 500 V range) Approx. 15 hours (with Z3210 installed, using wireless communications, comparator off, backlight off, measured with measurement terminal open at 500 V range)
Dimensions	Approx. 160W × 98H × 46D mm (6.3W × 3.86H × 1.81D in.) (excluding protrusions)
Mass	Approx. 536 g (18.9 oz.) (including battery and protector, excluding test lead)
Product warranty period: 3 years	
Fuse (Replacements)	FF0.5 AH/1000 V (70 172 40.0.500: SIBA GmbH) (Very fast-blow, arc-extinguishing material included, high breaking capacity)
Accessories	See “Verifying Package Contents” (p. 6)
Options	See “Options” (p. 7)

4.2 Basic and Accuracy Specifications

Measurement item	Insulation resistance measurement: DC voltage supply, current detection Low resistance measurement: DC current supply, voltage detection Voltage measurement: Automatic DC/AC detection AC voltage measurement rectification method: Mean rectification RMS value indication
Function settings	Ω , OFF, V, 50 V, 125 V, 250 V, 500 V, 1000 V
A/D conversion method	$\Delta\Sigma$ method
Input/output terminals	LINE terminal: Connect red test lead. Insulation resistance measurement: Terminal (-) to which current from the measurement target flows Terminal (-) to which current from the measurement target flows Low resistance measurement: Current output terminal Voltage measurement: + terminal EARTH terminal: Connect black test lead. Insulation resistance measurement: Voltage output terminal (+) Low resistance measurement: Terminal to which current from the measurement target flows Voltage measurement: - terminal
Maximum rated voltage to terminal	600 V AC/DC (Voltage measurement)
Maximum rated voltage to earth	600 V AC/DC (Measurement Category III) Anticipated Transient Overvoltage: 6000 V

Rated operational conditions	Ambient temperature: See "Operating temperature and humidity" in "4.1 General Specifications" (p. 57) Relative humidity: See "Operating temperature and humidity" in "4.1 General Specifications" (p. 57) Position: Standard position $\pm 90^\circ$ External magnetic field: 400 A/m or less Battery voltage: Available effective battery voltage
Nominal circuit voltage*	600 V AC/DC max. *: The nominal circuit voltage refers to the nominal voltage of an electric distribution circuit that can be measured by the instrument (based on EN 61557).
Accuracy guarantee conditions	Accuracy guarantee period: 1 year Accuracy guarantee period after adjustment made by Hioki: 1 year Accuracy guarantee temperature and humidity range: $23^\circ\text{C} \pm 5^\circ\text{C}$ ($73^\circ\text{F} \pm 9^\circ\text{F}$), 90% RH or less Position: Standard position $\pm 5^\circ$ External magnetic field: None (Earth's magnetic field) Battery voltage: Available effective battery voltage

Insulation Resistance Measurement					
Rated measurement voltage (DC)	50 V	125 V	250 V	500 V	1000 V
Effective maximum displayed value	100 M Ω	250 M Ω	500 M Ω	2000 M Ω	4000 M Ω
Medium displayed value	2 M Ω	5 M Ω	10 M Ω	50 M Ω	100 M Ω
1st effective measuring range [M Ω]	0.200 to 10.00	0.200 to 25.0	0.200 to 50.0	0.200 to 500	0.200 to 1000
Accuracy (Tolerance)	$\pm 2\%$ rdg ± 2 dgt				
2nd effective measuring range [M Ω]	10.1 to 100.0	25.1 to 250	50.1 to 500	501 to 2000	1010 to 4000
Accuracy (Tolerance)	$\pm 5\%$ rdg				
Other measuring range [M Ω]	0 to 0.199				
Accuracy (Tolerance)	$\pm 2\%$ rdg ± 6 dgt				

Insulation Resistance Measurement (continued)						
Range configuration	Display range	1 M Ω	1 M Ω	1 M Ω	1 M Ω	1 M Ω
	Maximum displayed value	1.000 M Ω	1.000 M Ω	1.000 M Ω	1.000 M Ω	1.000 M Ω
	Resolution	0.001 M Ω	0.001 M Ω	0.001 M Ω	0.001 M Ω	0.001 M Ω
	Display range	10 M Ω	10 M Ω	10 M Ω	10 M Ω	10 M Ω
	Maximum displayed value	10.00 M Ω	10.00 M Ω	10.00 M Ω	10.00 M Ω	10.00 M Ω
	Resolution	0.01 M Ω	0.01 M Ω	0.01 M Ω	0.01 M Ω	0.01 M Ω
	Display range	100 M Ω	100 M Ω	100 M Ω	100 M Ω	100 M Ω
	Maximum displayed value	100.0 M Ω	100.0 M Ω	100.0 M Ω	100.0 M Ω	100.0 M Ω
	Resolution	0.1 M Ω	0.1 M Ω	0.1 M Ω	0.1 M Ω	0.1 M Ω
	Display range	–	250 M Ω	500 M Ω	1000 M Ω	1000 M Ω
	Maximum displayed value	–	250 M Ω	500 M Ω	1000 M Ω	1000 M Ω
	Resolution	–	1 M Ω	1 M Ω	1 M Ω	1 M Ω
	Display range	–	–	–	2000 M Ω	4000 M Ω
	Maximum displayed value	–	–	–	2000 M Ω	4000 M Ω
	Resolution	–	–	–	10 M Ω	10 M Ω
	Intrinsic uncertainty (A)	±5% rdg (1st effective measuring range)				
Operation uncertainty (B)	±12% rdg (1st effective measuring range)					

Insulation Resistance Measurement (continued)			
	1st effective measuring range	2nd effective measuring range	Other measuring range
Fluctuations caused by temperature effects (E_3)*	$\pm 4\%$ rdg (0°C to 50°C)	$\pm 8\%$ rdg (0°C to 50°C)	$\pm 2\%$ rdg ± 6 dgt (0°C to 50°C)
	$\pm 8\%$ rdg (Greater than or equal to -25°C and less than 0°C, or greater than 50°C and less than or equal to 65°C)	$\pm 16\%$ rdg (Greater than or equal to -25°C and less than 0°C, or greater than 50°C and less than or equal to 65°C)	$\pm 4\%$ rdg ± 12 dgt (Greater than or equal to -25°C and less than 0°C, or greater than 50°C and less than or equal to 65°C)
Effect of humidity	$\pm 4\%$ rdg and within allowance	$\pm 8\%$ rdg and within allowance	$\pm 2\%$ rdg ± 6 dgt
Effect of magnetic field	$\pm 2.4\%$ rdg	–	–
Fluctuations caused by positioning effect (E_1)	Not applicable		
Fluctuations caused by supply voltage effects (E_2)	$\pm 4\%$ rdg and within allowance	$\pm 8\%$ rdg and within allowance	$\pm 2\%$ rdg ± 6 dgt and within allowance
Effects of capacitance components	Within $\pm 10\%$ for capacitance of 5 μ F or less (including variation)		

*: Applicable to the operating temperature range other than 18°C to 28°C.

Rated measurement voltage (DC)	50 V	125 V	250 V	500 V	1000 V
Possible number of measurements	1000 times or more				
Overload protection	600 V AC (10 s)			660 V AC (10 s)	

Insulation Resistance Measurement (continued)						
Display update interval	Within 0.6 s (no update during response)					
Measurement terminal voltage characteristic	Open-circuit voltage	1 to 1.2 times of rated measurement voltage				
	Lower limit resistance value to be maintained rated measurement voltage	0.05 M Ω	0.125 M Ω	0.25 M Ω	0.5 M Ω	1 M Ω
	Rated current	1 mA to 1.2 mA				
	Short-circuit current	1.2 mA or less				
	Response time	Within 0.6 s (with resistance load)				
Judgment time	Within 0.3 s (When switching from an open state to 10 times the default judgment reference value)					

Low Resistance Measurement				
Open-circuit voltage	4.0 V to 6.9 V			
Measuring current	200 mA or more (display value before zero adjustment at 6 Ω or less)			
Operation uncertainty	$\pm 30\%$ rdg (in 0.2 Ω to 2 Ω range) (Calculated based on EN61557)			
Effect of temperature*	$\pm 3\%$ rdg ± 2 dgt (applied in the operating temperature range excluding 18°C to 28°C)			
Effect of supply voltage*	$\pm 3\%$ rdg ± 2 dgt and within allowance			
Response time	Within 1 s (measurement terminal open \rightarrow short)			
Possible number of measurements	200 times or more			
Overload protection	600 V AC 10 s (by fuse protection)			
Zero adjustment range	0 Ω to 3 Ω			
Display update interval	Within 1 s			
Range configuration	Display range (Auto range)	Maximum displayed value	Resolution	Accuracy*
	10 Ω	10.00 Ω	0.01 Ω	± 3 dgt (0 Ω to 0.19 Ω) $\pm 3\%$ rdg ± 2 dgt (0.20 Ω to 10.00 Ω)
	100 Ω	100.0 Ω	0.1 Ω	$\pm 3\%$ rdg ± 2 dgt
	1000 Ω	1000 Ω	1 Ω	

*: Display value is applicable after zero adjustment

(When the temperature changes more than 1°C, zero adjustment is necessary.)

Voltage Measurement				
AC/DC automatic detection range	AC detected at 30 V or greater (50 Hz/60 Hz). (pulsating currents with an overlapping AC component of 30 V or more are detected as AC)			
Effect of temperature	Measurement accuracy per $1^{\circ}\text{C} \times 0.1$ (applied in the operating temperature range excluding 18°C to 28°C)			
Overload protection	750 V AC (10 s), 750 V DC (10 s)			
Display update interval	Within 1 s			
AC Voltage Measurement	Input resistance	100 k Ω or more (50 Hz/60 Hz)		
	Response time	Within 1.2 s (when input voltage is changed from 0 V to 600 V)		
	Frequency range	50 Hz/60 Hz		
	Range configuration			
	Display range (Auto range)	Maximum displayed value	Resolution	Accuracy
	420 V (minimum displayed value: 30.0 V)	420.0 V	0.1 V	$\pm 2.3\%$ rdg ± 8 dgt (ranges in excess of 600 V are outside the accuracy guarantee)
	600 V	750 V	1 V	
DC Voltage Measurement	Input resistance	100 k Ω or more		
	Response time	Within 1.2 s (when input voltage is changed from 0 V to 600 V)		
	Range configuration			
	Display range (Auto range)	Maximum displayed value	Resolution	Accuracy
	4.2 V	4.200 V	0.001 V	$\pm 1.3\%$ rdg ± 4 dgt (ranges in excess of 600 V are outside the accuracy guarantee)
	42 V	42.00 V	0.01 V	
	420 V	420.0 V	0.1 V	
600 V	750 V	1 V		

4.3 Functionality specifications

Live circuit indicator

Turns on when voltage is detected between the **LINE** terminal and the **EARTH** terminal.

Operates with all functions other than OFF.

Function	Status	Voltage across terminals	Live circuit indicator
Insulation resistance measurement	MEASURE key on	–	Lights up
	MEASURE key off (during automatic discharge)	5 V DC or more	Blinks
	MEASURE key off (except during automatic discharge)	30 V AC or more, +20 V DC or more, -20 V DC or less	Blinks (Buzzer sounding)
		5 V AC or less, +5 V DC or less, -5 V DC or more	Turns off
Low resistance measurement	MEASURE key on	–	Lights up in red
	MEASURE key off	30 V AC or more, +5 V DC or more, -5 V DC or less	Blinks (Buzzer sounding)
		1 V AC or less, +1 V DC or less, -1 V DC or more	Turns off
Voltage measurement	MEASURE key on or off	30 V AC or more, +20 V DC or more, -20 V DC or less	Blinks
		5 V AC or less, +5 V DC or less, -5 V DC or more	Turns off

Automatic electric discharge	Automatically discharges the electric charge still present in the capacitance of the measuring object after the insulation resistance measurement.
	Bar graph display of residual voltage
	<ul style="list-style-type: none">• Discharge resistance: 800 kΩ or less• Maximum capacitive load: 5 μF• Discharge time: Max. 30 s (when connected to 5 μF)
Auto power save (APS)	The power will go off automatically approx. 10 minutes after the last operation or last live circuit indicator display. <ul style="list-style-type: none">• To cancel: Can be canceled using the power supply activation options.• Returning from auto power save: The instrument turns back on when the rotary switch is temporarily returned to the off position.
Display	Semi-transmissive FSTN liquid crystal, positive

Bar graph display

Enabled during insulation resistance measurement

- When MEASURE key is on: Insulation resistance value is displayed.
- During discharge operation following insulation resistance measurement: Residual voltage is displayed.
- While holding measured value: Insulation resistance value is displayed.

The resistance value graduation is displayed after rounding values down to one significant digit. (For example, if the display value is 5.99 M Ω , the bar graph will display a 5 M Ω graduation.)

Graduations (unit: M Ω)

●: Graduation accompanied by value

●0					0.05				
	●0.1	0.2	0.3	0.4	●0.5	0.6	0.7	0.8	0.9
	●1	2	3	4	●5	6	7	8	9
	●10	20	30	40	●50	60	70	80	90
	●100	200	300	400	●500	600	700	800	900
	●1000	2000	3000	4000					
●∞									

4

Battery capacity warning voltage

Battery voltage	Number of remaining battery capacity gauge marks
5.3 V \pm 0.19 V or more	3
4.9 V \pm 0.19 V or more, less than 5.3 V \pm 0.19 V	2
4.5 V \pm 0.19 V or more, less than 4.9 V \pm 0.19 V	1
less than 4.5 V \pm 0.19 V	0 (flashing battery outline)

Hysteresis: The battery capacity gauge will not return to its previous state until the instrument is turned back on, even if the battery voltage rises.

Measurement cannot be performed if the capacity gauge indicates zero. (Measured values will not be displayed.)

Backlight	<ul style="list-style-type: none"> • Color: white, red • Light automatic OFF function: Available (White only. The instrument will turn off automatically about 3 minutes after the last operation, or after the last active line warning is displayed.) • Turns red when the comparator judgment result is FAIL. (When the white backlight is active, the white backlight turns off, and the red backlight turns on.) • Operation at erroneous input: Alternates white and red in the following circumstances: <ol style="list-style-type: none"> (1) Insulation resistance measurement function: When a voltage greater than or equal to the voltage that triggers an active line warning is input (2) Voltage measurement function: When a voltage that is greater than or equal to negative or positive full scale is input
500 V/1000 V inadvertent voltage application prevention function	<p>Prevents inadvertent application of voltage to low-voltage devices when using the 500 V or 1000 V range.</p> <ul style="list-style-type: none"> • Unlock method: RELEASE key operation • When locked: The PRESS RELEASE KEY mark lights up and the RELEASE key flashes. • Relock function: After being unlocked, the instrument will return to the locked state about 1 minute after the last key operation.
Blown fuse detection	<p>Notifies the user if the fuse for protecting the low-resistance measurement circuit has blown.</p> <ul style="list-style-type: none"> • If the user tries to measure a low resistance while the circuit's protective fuse has blown, the blown fuse indicator will flash. • Low-resistance measurement measured values are not displayed when the fuse is blown.
Firmware update function	<p>The instrument's firmware can be updated using GENNECT Cross.</p> <p>Required: GENNECT Cross (Ver. 1.8 or later)Instrument firmware (Ver. 2.00 or later)</p>

Power-on Options

Canceling the power-saving function (p.36)	Turn on the instrument while holding down the LIGHT key.
Displaying the serial number	Turn on the instrument while holding down the RELEASE key. The serial number will be displayed three digits at a time. In the following example, the month and year of manufacture are May 2021. Example: [210] → [512] → [345] After checking the number, set the rotary switch to OFF.
Checking the HID setting (p.55)	<ol style="list-style-type: none"> 1. Turn on the instrument while holding down the RELEASE key. The serial number screen will be displayed. 2. Press RELEASE key for 3 s or more. The HID setting saved by the Z3210 will be displayed.
Displaying the software version	<ol style="list-style-type: none"> 1. Turn on the instrument while holding down the 0 Ω ADJ key and the COMP key. 2. Press the RELEASE key while the [vEr] display is active. The display will alternate between the version number [vx.xx] and model [4059]. After checking the number, set the rotary switch to OFF.

4.4 Other Specifications

Default condition and setting backup

Item	Factory default	Setting backup
APS	Enabled	No
Comparator	Enabled For initial values, see "Setting the Comparator" (p. 39)	Yes (on/off, setting value)
Zero adjustment	Disabled	Yes (on/off, zero adjustment value)
Wireless communication function settings	Enabled When the instrument is turned on for the first time after installing the Z3210	Yes (on/off)

**When
operating with
a low supply
voltage**

The instrument will enter the auto power save state when the supply voltage falls to 4.0 ± 0.3 V or lower, even if auto power save is set to "off."

 **WARNING**

Touching any of the high-voltage points inside the instrument is very dangerous. Customers are not allowed to modify, disassemble, or repair the instrument. Doing so may cause fire, electric shock, or injury.

Calibrations

The calibration period varies with the conditions and environment of use. It is recommended to determine a calibration period based on those factors and to have the instrument regularly calibrated by Hioki. Please contact your authorized Hioki distributor or reseller to have your instrument periodically calibrated.

Precautions when transporting the instrument

When transporting the instrument, be sure to observe the following precautions:

- To avoid damage to the instrument, remove the batteries from the instrument. Moreover, be sure to pack in a double carton. Damage that occurs during transportation is not covered by the warranty.
- When sending the instrument for repair, be sure to include details of the problem.

Disposal

Handle and dispose of the instrument in accordance with local regulations.

Cleaning

- If the instrument becomes dirty, wipe the instrument clean with a soft cloth slightly moistened with water or a neutral detergent.

IMPORTANT

Never use solvents such as benzene, alcohol, acetone, ether, ketones, thinners or gasoline. Doing so could deform and discolor the instrument.

- Wipe the display gently with a soft, dry cloth.
- Wipe the dust from metal parts of alligator clips with a soft cloth to avoid any impact on the measurements.

5.1 Troubleshooting

Before Returning for Repair

If damage is suspected, check the following before contacting your authorized Hioki distributor or reseller.

Symptom	Check Items	Remedy and Reference
The power is not turning on.	Does the battery have sufficient charge?	Replace with the new batteries. (p.27)
	Have the batteries been installed improperly?	Install the batteries in the proper orientation.(p.27)
The batteries run out immediately.	Are you using alkaline batteries?	Replace the batteries with alkaline batteries.(p.27)
The MEASURE key is not working for the lead with a switch.	Is the plug of the lead with a switch fully inserted?	Fully insert the plug to the limit without any gaps. (p.31)
During insulation resistance or low resistance, the live circuit indicator and the display blinks in red, and the buzzer sounds.	Does the voltage applied between the measurement terminals exceed the following values? Insulation resistance: approx. 20 V Low resistance: approx. 5 V	Make sure that the measuring object is disconnected from a live circuit. If voltage exists in the measuring object, the live circuit indicator* blinks. * The live circuit indicator may be blink even when an induction potential is generated.

Symptom	Check Items	Remedy and Reference
Unable to perform measurement.	Are you setting the rotary switch while the MEASURE key turned on?	Turn off the MEASURE key and then press it again.
	Is the voltage between the measuring terminals over any of the following values before turning on the MEASURE key? 50 V to 250 V range: Approx. 90 V 500 V range: Approx. 500 V 1000 V range: Approx. 1000 V	Separate the measuring object from all sources of power before performing measurement.
Unable to perform measurement in 500 V range or 1000 V range.	Is the instrument locked so as to prevent inadvertent voltage application?	Release the lock function. (p.42)
In the 500 V range or 1000 V range, turning on the MEASURE key enables the lock function that has been released.	Is the battery new? Does the battery have sufficient charge? Are alkaline batteries or nickel-metal hydride batteries used?	Replace the batteries with fresh alkaline batteries or fully charged nickelmetal hydride batteries.* ¹ (p.27)
	Is the temperature low (0°C or less)?	Remove and warm the batteries. Otherwise, replace them with fresh Alkaline batteries or fully charged Nickel-metal hydride batteries. (p.27)
	Has 1 minute lapsed after the last operation?	Release the lock function again. (p.42)

Symptom	Check Items	Remedy and Reference
The measured value is shown as the maximum display value.	Is there a broken connection in a test lead?	Check the continuity of the test lead with a tester.
	Are the test leads securely connected?	Check the connection between the test leads and the instrument, and check the connection of the tips of the test leads.
Measured values vary and fail to stabilize.	Is a charging circuit located near the measurement object?	Disconnect the circuit breaker for any nearby charging circuits. If this is not possible, use the lowest measured value as the measurement result.
Measured values acquired through insulation resistance measurement fluctuate over time.	When the measuring object connected is a capacitor: Does the measuring object have a large capacitance component (capacitor)?	If it is possible to remove the capacitor, do so. If not, use the lowest measured value as the measurement result.
	When the measuring object connected is not a capacitor: This phenomenon reflects the influence of the measuring object capacitance component. This is not a malfunction or error.	Select measured values acquired one minute after the start of the measurement. If a large capacitance component included in the measuring object causes the fluctuation of measured values, select measured values after they have stabilized.

Symptom	Check Items	Remedy and Reference
A different measured value results each time the same measuring object is measured.	Is there any impact due to the material of the measuring object?	Allow an adequate amount of time (about 1 hour to 1 day) to pass after the first measurement before repeating measurement. The effects of polarization* ² increase as the insulation resistance increases.
	Is there any impact due to the temperature/humidity characteristics of the measuring object?	Measure the object under the same temperature and humidity conditions. In general, an insulator's insulation resistance value will decrease as temperature and humidity increase. Reference: the insulation resistance value of some insulated cables decreases to 1/4 or less when the temperature increases 10°C.
The output voltage polarity is reversed.	The reversal is due to the characteristics of the insulation ohmmeter. This does not represent a malfunction.	—

Symptom	Check Items	Remedy and Reference
When the instrument is calibrated, the accuracy of the insulation resistance range falls outside the device specifications.	Has the supplied or optional test lead used?	Use the test leads that came with the instrument or its optional test leads to perform the calibration procedure. With standard wiring, characteristics are affected when the resistance in the 1000 V range reaches or exceeds 100 M Ω .
	Has the insulation of the test lead deteriorated?	Replace the deteriorated test lead with a new one.

- *1 Batteries with high internal resistance may not be able to deliver enough energy to power the instrument, even if you're using new alkaline batteries or batteries with sufficient charge. If the instrument does not operate even though its batteries have just been replaced, try batteries from a different manufacturer.
- *2 Polarity: A phenomenon whereby a substance's positive and negative electric charges move in opposite directions when an electric field is applied to it, causing the center position of the positive and negative charges to shift.

Errors and status codes

When an error is displayed on the LCD screen, repair is necessary. Please contact your authorized Hioki distributor or reseller.

Code	Description	Remedy and Reference
Err 0ΩADJ	Zero adjustment is outside the allowable range. (Low resistance measurement)	<ul style="list-style-type: none"> Verify that there is no broken connection in the test leads. Zero adjustment can be performed for readings of up to 3 Ω. Ensure that the wiring resistance is 3 Ω or less. (p.48)
Err1	Program data corrupt.	Repair is required.
Err2	Adjustment data damaged.	
Err4	The EEPROM used to store settings data has failed (including failure to communicate with the EEPROM).	
Err5 01	Abnormality in measurement circuit.	Replace the batteries. If there is no apparent improvement, the instrument needs repair
Err5 02	Abnormality in voltage generation circuit.	
Err8	Z3210 communications error (connection failure; Z3210 or hardware failure)	Take the following actions (p.33): <ul style="list-style-type: none"> Reinstall the Z3210. Install a different Z3210. If the error persists, you are experiencing a instrument failure. Contact your authorized Hioki distributor or reseller to organize repair.
Err9	Firmware update error	Use GENNECT Cross to update the firmware again. (p.70)

Code	Description	Remedy and Reference
FUSE (blinks)	The protective fuse has tripped. (The fuse is user-replaceable.)	Replace the indicated fuse. (p.27)
APS → P.oFF	Powered off by APS.	–
bAtt → P.oFF	Instrument powered off due to supply voltage drop	Replace the batteries. (p.27)

Appx. 1 Measurement Principles

1. Insulation resistance measurement

The measuring object's insulation resistance R_x is calculated by applying a voltage V to the object, measuring the leak current I that flows to the object as a result, and dividing the voltage V by the leak current I .

2. Low resistance measurement

The measuring object's resistance R_x is calculated by applying a current I to the measuring object, measuring the voltage V that occurs between the measurement terminals as a result, and dividing the voltage V by the current I .

Appx. 2 Operation Uncertainty

The operation uncertainty and the variations of measurement value for the respective influence quantity approved by EN/IEC61557 are as follows:

Intrinsic uncertainty/ influence quantity		Operation range	Variation	
			Insulation resistance	Low resistance
A	Intrinsic uncertainty	Reference condition	±5% rdg	±3% rdg ±2 dgt
E ₂	Supply voltage	4.5 V to 6.8 V	±4% rdg	±3% rdg ±2 dgt
E ₃	Temperature	0°C to 35°C	±4% rdg	±3% rdg ±2 dgt
B	Operation uncertainty		±12% rdg	±30% rdg
Guaranteed range of operation uncertainty			1st effective measurement range	0.2 Ω to 2 Ω

Influencing factor non-applicable for E₁ and E₄ to E₁₀

Warranty Certificate

HIOKI

Model	Serial number	Warranty period Three (3) years from date of purchase (___ / ___)
-------	---------------	--

Customer name: _____
Customer address: _____

Important

- Please retain this warranty certificate. Duplicates cannot be reissued.
- Complete the certificate with the model number, serial number, and date of purchase, along with your name and address. The personal information you provide on this form will only be used to provide repair service and information about Hioki products and services.

This document certifies that the product has been inspected and verified to conform to Hioki's standards.

Please contact the place of purchase in the event of a malfunction and provide this document, in which case Hioki will repair or replace the product subject to the warranty terms described below.

Warranty terms

- The product is guaranteed to operate properly during the warranty period (three [3] years from the date of purchase).
If the date of purchase is unknown, the warranty period is defined as three (3) years from the date (month and year) of manufacture (as indicated by the first four digits of the serial number in YYMM format).
- If the product came with an AC adapter, the adapter is warranted for one (1) year from the date of purchase.
- The accuracy of measured values and other data generated by the product is guaranteed as described in the product specifications.
- In the event that the product or AC adapter malfunctions during its respective warranty period due to a defect of workmanship or materials, Hioki will repair or replace the product or AC adapter free of charge.
- The following malfunctions and issues are not covered by the warranty and as such are not subject to free repair or replacement:
 - 1. Malfunctions or damage of consumables, parts with a defined service life, etc.
 - 2. Malfunctions or damage of connectors, cables, etc.
 - 3. Malfunctions or damage caused by shipment, dropping, relocation, etc., after purchase of the product
 - 4. Malfunctions or damage caused by inappropriate handling that violates information found in the instruction manual or on precautionary labeling on the product itself
 - 5. Malfunctions or damage caused by a failure to perform maintenance or inspections as required by law or recommended in the instruction manual
 - 6. Malfunctions or damage caused by fire, storms or flooding, earthquakes, lightning, power anomalies (involving voltage, frequency, etc.), war or unrest, contamination with radiation, or other acts of God
 - 7. Damage that is limited to the product's appearance (cosmetic blemishes, deformation of enclosure shape, fading of color, etc.)
 - 8. Other malfunctions or damage for which Hioki is not responsible
- The warranty will be considered invalidated in the following circumstances, in which case Hioki will be unable to perform service such as repair or calibration:
 - 1. If the product has been repaired or modified by a company, entity, or individual other than Hioki
 - 2. If the product has been embedded in another piece of equipment for use in a special application (aerospace, nuclear power, medical use, vehicle control, etc.) without Hioki's having received prior notice
- If you experience a loss caused by use of the product and Hioki determines that it is responsible for the underlying issue, Hioki will provide compensation in an amount not to exceed the purchase price, with the following exceptions:
 - 1. Secondary damage arising from damage to a measured device or component that was caused by use of the product
 - 2. Damage arising from measurement results provided by the product
 - 3. Damage to a device other than the product that was sustained when connecting the device to the product (including via network connections)
- Hioki reserves the right to decline to perform repair, calibration, or other service for products for which a certain amount of time has passed since their manufacture, products whose parts have been discontinued, and products that cannot be repaired due to unforeseen circumstances.

HIOKI E.E. CORPORATION

<http://www.hioki.com>

18-07 EN-3

HIOKI

www.hioki.com/



**All regional
contact
information**

HIOKI E.E. CORPORATION

81 Koizumi, Ueda, Nagano 386-1192 Japan

2309 EN

Edited and published by HIOKI E.E. CORPORATION

Printed in Japan

- Contents subject to change without notice.
- This document contains copyrighted content.
- It is prohibited to copy, reproduce, or modify the content of this document without permission.
- Company names, product names, etc. mentioned in this document are trademarks or registered trademarks of their respective companies.

Europe only

- EU declaration of conformity can be downloaded from our website.
- Contact in Europe: HIOKI EUROPE GmbH
Helfmann-Park 2, 65760 Eschborn, Germany

hioki@hioki.eu