# ΗΙΟΚΙ

## CLAMP ON POWER HITESTER 3169-20, 3169-21

Power Measuring Instruments



Measure up to two 3-phase, 3-wire systems (displays voltage and current for three lines)
 Measure up to four single-phase, 2-wire systems

0.5 A to 5000 A range

 Compact and light weight

- PC card data storage
- Power recording for individual waveforms
- Simultaneous recording of demand values and harmonics
- POWER MEASUREMENT SUPPORT SOFTWARE 9625

CE

The photo shows the **3169-21** combined with **CLAMP ON SENSORS 9661** and 9669 (optional) for measuring two systems.

The **3169-20/21** can also be used in combination with **CLAMP ON SENSORS** (optional) rated up to 5000 A.

## Offering a new approach to energy-related measurement

0000

RL BRADLAIN

such as energy conservation, ISO14001 testing, equipment diagnosis, and harmonics measurement.

Measures power lines of up to 254 mm in diameter

FLEXIBLE CLAMP ON SENSOR CT9667 **CLAMP ON POWER HITESTERs are 3169-20 and 3169-21** that allow measurement of single-phase to three-phase 4-wire circuits with a single unit. In addition to measuring standard parameters such as voltage, current, power, power factor, and integrated values, these clamp-on power meters can simultaneously perform demand measurements required for carrying out power management and energy-saving measures, as well as harmonic measurements. The two new power meters also feature PC card data storage, and come equipped with an RS-232C interface for PC communications. Further, with greater data processing speeds, it is possible to measure the power of just a few cycles, enabling more detailed and effective energy-saving measures for equipment. The **3169-20** and **3169-21** are ideal for users who want to achieve close control over energy-saving management activities and measures.





and other information are available on our website



#### Measure power lines of up to four systems (with a common voltage)

One single unit can measure four circuits (single-phase 2-wire), two circuits (3-phase, 3-wire), or a one circuit (3-phase, 4-wire)system.

#### A wide range of measurement functions

The **3169-20/21** can simultaneously measure voltage, current, power (active, reactive, and apparent), integrated power, power factor, and frequency. Further, when using 3-phase, 3-wire (3P3W2M) mode, you can display the voltage and current for all three lines by measuring just two of them. When using the 3-phase, 4-wire (3P4W4I) mode, neutral line current can be displayed using 4 current measurement.

#### Equipped with ranges from 0.5 A to 5000 A

The power meters support seven types of clamp-on current sensors to enable measurement for a variety of items, from CT terminals to large current and thick power lines.

#### Supports high-speed data storage from individual waveforms

When using the standard mode to perform integrated power measurement, you can store data in intervals starting from one second, and when simultaneously measuring integration and harmonics, in intervals starting from one minute. When in the fast mode, you can store RMS data for individual waveforms.

#### PC Card compatible plus internal hard drive for extra memory

Store valuable measurement data in convenient PC cards. The internal memory (1 MB) supports measurement over extended periods and detailed measurement parameters.

#### Housed in a compact A5 body size

The **3169-20** and **3169-21** feature a compact design that makes them portable and easy to use in tight spaces, and are approximately 30% more compact than the CLAMP ON POWER HITESTER 3166.

#### Multi-language Compatibility

Select from nine languages, including Japanese and English.

#### Detect incorrect connection using vector diagrams

Use the vector display on the connection confirmation screen to check the phase, whether a connection is loose, or whether the clamp-on sensor connection has been reversed during VT/CT terminal measurement.

## Polarity display and measurement using the reactive power measurement method

The units come equipped with a polarity display for checking LAG/ LEAD when measuring power factor or reactive power. Further, you can select the reactive power measurement method, or display the phase factors for RMS values and power comparison.

#### High-speed D/A output

The **3169-21** comes equipped with 4-channel high-speed D/A output to enable analog output of RMS values for individual waveforms.

#### Ideal for power and harmonics management

The power meters come equipped with a harmonics measurement function that supports measurement of 3-phase power lines. They can also perform simultaneous measurement of harmonics and demand values, enabling both power and harmonics management.

## The ultimate in clamp-on power meters!



External I/O terminal pin placement

Pin	Signal name	Pin	Signal name
1	Start/stop input	4	Data storage input
2	Free	5	GND
3	Status output		

### **Range Configuration Table**

Use the CONNECTION CABLE 9440 to connect to external devices.

$\bigwedge$		CLAMP ON SE	ON SENSOR 9695-02		CLAMP ON SENSOR 9661				
		(CAT II	( 300V)	(5A, 10A, 50A, 100A, 500A)					
Current		(500mA, 1A, 5.	A, 10A, 50A)						
	$\backslash$	CLAMP ON SENSOR 9694 (CAT III 300V) (500mA, 1A, 5A)			CLAMP ON SENSOR 9660, 9695-03 (CAT III 300V) (5A, 10A, 50A, 100A)				
Voltage	Connection	500.00mA	1.0000A	5.0000A	10.000A	50.000A	100.00A	500.00A	
	Single-phase 2-wire	75.000 W	150.00 W	750.00 W	1.5000kW	7.5000kW	15.000kW	75.000kW	
150.00V	Single-phase 3-wire Three-phase 3-wire	150.00 W	300.00 W	1.5000kW	3.0000kW	15.000kW	30.000kW	150.00kW	
	Three-phase 4-wire	225.00 W	450.00 W	2.2500kW	4.5000kW	22.500kW	45.000kW	225.00kW	
	Single-phase 2-wire	150.00 W	300.00 W	1.5000kW	3.0000kW	15.000kW	30.000kW	150.00kW	
300.00V	Single-phase 3-wire Three-phase 3-wire	300.00 W	600.00 W	3.0000kW	6.0000kW	30.000kW	60.000kW	300.00kW	
	Three-phase 4-wire	450.00 W	900.00 W	4.5000kW	9.0000kW	45.000kW	90.000kW	450.00kW	
	Single-phase 2-wire	300.00 W	600.00 W	3.0000kW	6.0000kW	30.000kW	60.000kW	300.00kW	
600.00V	Single-phase 3-wire Three-phase 3-wire	600.00 W	1.2000kW	6.0000kW	12.000kW	60.000kW	120.00kW	600.00kW	
	Three-phase 4-wire	900.00 W	1.8000kW	9.0000kW	18.000kW	90.000kW	180.00kW	900.00kW	

$\searrow$	Quinnant	CLAM	ON SENSO	DR 9669		$\searrow$	Current.	FLEXIBLE CLAMP (	ON SENSOR CT9667
Voltage	Current	100.00 A	200.00 A	1.0000kA		Voltage	Connection	500.00 A	5.0000kA
	Single-phase 2-wire	15.000kW	30.000kW	150.00kW			Single-phase 2-wire	75.000kW	750.00kW
150.00V	Single-phase 3-wire Three-phase 3-wire	30.000kW	60.000kW	300.00kW		150.00V	Single-phase 3-wire Three-phase 3-wire	150.00kW	1.5000MW
	Three-phase 4-wire	45.000kW	90.000kW	450.00kW		Three-phase 4-wire	225.00kW	2.2500MW	
	Single-phase 2-wire	30.000kW	60.000kW	300.00kW		300.00V	Single-phase 2-wire	150.00kW	1.5000MW
300.00V	Single-phase 3-wire Three-phase 3-wire	60.000kW	120.00kW	600.00kW			Single-phase 3-wire Three-phase 3-wire	300.00kW	3.0000MW
	Three-phase 4-wire	90.000kW	180.00kW	900.00kW		Three-phase 4-wire	450.00kW	4.5000MW	
	Single-phase 2-wire	60.000kW	120.00kW	600.00kW	1		Single-phase 2-wire	300.00kW	3.0000MW
600.00V	Single-phase 3-wire Three-phase 3-wire	120.00kW	240.00kW	1.2000MW		600.00V	Single-phase 3-wire Three-phase 3-wire	600.00kW	6.0000MW
	Three-phase 4-wire	180.00kW	360.00kW	1.8000MW	1		Three-phase 4-wire	900.00kW	9.0000MW

Note 1:The range configuration table displays the full-scale display values for each measurement range. Note 2:In the table, "unit W" has been replaced with "VA" or "var" for the apparentpower and reactive power measurement ranges. Note 3:Voltage and current input values 0.4% or less than the measurement range are displayed as "zero". When either the voltage or current for the power line is zero, the power value is displayed as zero. Note 4:You can display measurement values up to 130% of each measurement range.

### Measure hidden power waste through secure connections, simple measurement methods, and detailed data capture.

## **Promises reliable measurement for power demand** requirements!

### Select from a variety of data, including detailed and harmonics data for multiple circuits

#### ★ To measure multiple systems simultaneously

4

A single unit can measure two three-phase, 3-wire systems. Further, you can make individual clamp-on sensor and current range settings for each system.

Also, in addition to performing simultaneous measurement for up to four systems (single-phase, 2-wire) with a common voltage, you can set the current range individually for each system. Setting the most suitable current range for both large and small loads allows you to acquire more accurate measurements.



#### Magnetic voltage adapters for hard-to-clip terminals New magnetic voltage adapters convertible with the Voltage Cords L9438-53

let you accurately detect voltage when the circuit terminals are too shallow for alligator clips to latch on.





generally compatible with M6 pan screws

#### \* Simultaneous power and harmonics management

Use a single unit to simultaneously measure data for power and harmonics.

#### All acquired data can be saved onto a PC card.

Power data (including demand data) and harmonics data can be simultaneously saved onto a PC card or in the unit's internal memory. Further, data for all of the systems being measured can be saved when measuring multiple circuits. Each of these two new unit's offers a management system for power and harmonic quality.



#### ★ When measurement accuracy is crucial

#### The addition of a vector display for viewing the connection status completes the preparation required for measurement.

Have you ever experienced incorrect measurement results?

The most common cause of incorrect data is a faulty connection. With the **3169-20/21** you can use the vector display to check the phase, whether a connection is loose, or whether the clamp-on sensor connection has been reversed.

Also, you are assured of proper connection when measuring the VT (PT)/CT terminals even if you cannot see the line you are measuring



#### The basic settings are constantly displayed, allowing you to measure with confidence.

During measurement, in addition to displaying the voltage and current ranges, and VT (PT) and CT ratios for each system, the unit can also display items such as the measurement interval. Because the basic settings are constantly visible, you can be confident of obtaining the correct measurement results.

#### ★ Capture facility data quickly

#### By using continuous processing to measure individual waveforms, you can accurately measure data in a relatively short amount of time.

Use the desired measurement method to continuously measure the voltage, current, and power for individual waveforms, enabling you to obtain accurate data in one second or less. Further, you can record the maximum, minimum and average values

					_				-			
					Μ	AIN		INST.	CII	RCUIT	1 _	
				MATN	A	VF	CTF	CUTT		200	3	
			_	1011219		V .L	on		L	1	492	A
		MAIN		MIN.	CIRC	UIT1		2002	2/05/19	U U	96	A
MA	IN	MAX.	CIF	CUITI		2002	05/19	U U	300V	T	94	Ą
						10	2000U	×	1.00	×	24	Å.
111	201	11 V	T1	<u> </u>	92 A	U.	1.00		10A	I4 ×	18	H.
Ĭ2	201	lii v	Ť2	ģģ	97 A	Т	10A	I4	1.00 5A	WT	121)	K Ma
Ŭ3	201	. ÔÔ Ý	Ĩ3	<u> </u>	94 A	×	1.00	X	1.00 DING	ar l'	1201	< VP
Uav	ve 201	.06 V	Iave	9.9	94 A	I4 ×	1.00	WI	KING -	CI CI	ISZ.	
			I4	0.16	32 A	WIF	RING	r <sub>ct</sub>	RCUITT	ľ	98	H2
P1	1.7	435kW	Q	2.99	21k var	. 3	3P4W4I		×1	e PLI	-00	
P2	1.7	462kW	ŝ	6.02	78kVA	CIF	CUIŢ	PLL	. U1	TN		
P3	1.7	'437kW	PF	0.86	85		×1		50Hz		1	
P	5.2	329kW	f	50.0	10 Hz	PLL	U1 50Hz	IN	TVL.		ī	
WP-	+ 0.00	000kWh		0:00:	00	TNT	W		1min		9	
						TIM	1min	H	OLD			
SC	CREEN		MIN	IMUM		HC	)LD					

#### ★ Measure another device simultaneously

#### Using the external I/O function, you can obtain even more detailed measurements for energy conservation.

In addition to measurement start/stop control through external input, you can use this function to output the measurement start/stop signal for the 3169-20/21. Simultaneous recording of a variety of signals is also possible for equipment when using multiple devices to perform start control and multi-channel recording.



Large storage capacity to accommodate power and harmonics data for individual waveforms. Supports energy saving measures that can be carried out from your PC.

## Greater flexiblity for energy saving measures through detailed measurement!

### Reduce energy consumption by "1%"! Why not try analyzing your energy saving measures?

#### ★ Save measurement details to PC card for extended measurements! Why not try a shorter data management interval?

With the 3169-20/21, you can set the data recording interval to 1 minute. If you are unsure how to proceed with energy conservation, you can use a large capacity PC card to save measurement details, then use the data to create a load fluctuation graph and analyze this to help reduce wasted power consumption.

Further, because you can save a variety of data, including simultaneous recording of power and harmonics data, waveform data storage, and print-outs of the screen, these two new units help by storing measurement details



★ Identify even small amounts of power waste using individual waveform measurements

The 3169-20/21 can help turn you into a keen energy saving specialist These two new units allow you to measure power data by recording the RMS values for individual waveforms

By measuring just a few seconds of machine cycles or changes in operating patterns of facilities such as manufacturing equipment, you can grasp power fluctuations over a relatively short amount of time and view improvements in the form of numerical data. Gain unsurpassed energy savings by achieving simple improvements around the work environment



#### ★ Improve energy-saving operations and create an energy-efficient facility

Why not try to improve your energy-saving measures using the 3169-21?

Using the D/A output (4 ch) function on the 3169-21, you can simultaneously record a variety of measurement and control signals for equipment, such as the power fluctuation and temperature/flow for individual waveforms, onto a HIOKI MEMORY HICORDER or logger.

A slight reduction in power consumption due to changes in the inverter motor operating patterns or temperature settings equals to an energy-saving effect.



★ Unbalanced loads are an enemy to energy saving activities. Solve your problems with careful management of power lines.

#### Unbalanced 3-phase loads can result in a damaged power line.

To provide detailed management of measurements, the 3169-20/21 displays voltage and current for all three lines even when measuring just two circuits (3P3W2M). Further, because the effective power for each phase is displayed based on a virtual center point when measuring the voltage and current for all three lines (3P3W3M), the units can also be used to implement energy saving measures and power management systems.



#### ★ Harmonics cause wasted power

Did you think that harmonics and energy saving activities were unrelated? Due to a spread in equipment that uses semiconductor control devices, such as inverters, power quality has decreased. Also, power consumed in harmonic components is all wasted power. Harmonic control and management are essential for energy conservation.



★ To identify causal factors with harmonic measurements of multiple systems circuits If production equipment malfunctions, power is wasted if repeated manufacture results in defective products again.

If you think harmonics are causing malfunctions, you can simultaneously measure the harmonics of individual circuits using multi-circuit measurement to obtain detailed information about the occurrence of harmonics along with the current direction for each phase. Using the 3169-20/21 you can accurately determine the relationship for harmonic inflow and outflow between power lines by analyzing the data acquired simultaneously, and then devising energy-saving measures based on the cause of the occurrence.

5

## POWER MEASUREMENT SUPPORT SOFTWARE 9625

# ■Graphically process measurement data from Model 3169-20/21 easily on a PC!

The **POWER MEASUREMENT SUPPORT SOFTWARE 9625** application provides easy graphical processing on a computer of measurement data saved on **CLAMP ON POWER HITESTERS 3169-20/21** and **3166**.



#### **Features**

#### Time Series Graph Display Function

Measurement data can be displayed as a time series graph. Demand data measured in different series can be overlaid on the display.

#### Summary Display Function

Measurement data can be displayed directly in table form.

#### Daily, Weekly and Monthly Report Display Function

Daily, weekly and monthly reports of demand data can be displayed.

#### Harmonic Analysis Function

Display harmonic measurement data as a graph, list or waveform. (Also compatible with the harmonic measurement data captured by Model **3166**.)

#### Print Function

Each screen can be printed.

#### Easily display and print various screens such as graphs and spreadsheet tables

#### Step 1. Load measurement data

Load up to 16 data sets from the **3169-20/21** or **3166** at once. Measured numerical values and waveform data are recognized and displayed automatically.

- Loading and deleting data, and changing data names, can be done easily.
   Multiple sets of measurement data can be loaded and managed in a single
- file.





#### Time Series Graph Display Function (two-axes display possible)

■ The displayed graph can be set to suit particular start/stop times and data intervals. Harmonic time series graphs can be displayed.

#### **Convenient Functions**

- (1) The horizontal (time) axis can be easily scrolled to show the desired range.
- (2) Upper and lower limits (measurement values) of the vertical axis can be easily set and changed.
   \* Graph type (line, bar or stacked bar), line type (such as solid or dashed),
  - color and details of upper and lower numerical values can be set.
- (3) Any desired numerical data value on a graph can be confirmed and displayed by cursor movement.
- (4) The display can be switched between 2D and 3D graphs.

#### Summary Display Function

#### Summary

 Displays a summary of the data values between specified start/ stop times, at the specified data interval.

#### Convenient Functions

- In addition to measurement values within the period being displayed, the summary shows period, maximum, minimum and average values.
- (2) Measurement data names and measurement units can be edited in the summary.

#### Daily, Weekly or Monthly Report Display

 Displays a summary covering the total values in daily, weekly or monthly reports.

#### Convenient Functions

- The time axis for each total scrolls to easily change the totalized period.
- (2) The total time range of measurement data can be totalized in up to four sections per time period.

Analyzed Sector of Landson and	tran and Delated	traine (mail)		
Territoria Processo (1999) - Processo (1999) Processo (1999) - Processo (1999) Processo (1999)	magnet 5			
a local from a first of	Terme			Type
W Inwest (Mass. or - Front	# 20000 1 -			Pineter of
	a level 75			Terestria
Witness Frees - Frees -	× 20.000 /~	-		and with
Flores (100 g - (100 -	=long [5	an al a press		Parity on

Upper/Lower

Limit Setting

Slider



	241	- [1010001]	* *					
2	The Act of Bolgood States and the post of any of the	UI 1994 gr CH 1994 AU 1994 50 1994 AU 1994 50 1994 AU 1994 50 1994 50	2 100 00 000 100 000 000 100 000 100 000 100 000 100 000 100 000 100 000	H General de Canal - PERITECTOR R PERITECTOR R PERITECTOR	0 Grant (10 bettersteine) Grant ( Ward (2014) 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8	A Annual State Charles FEREICALISMAN N STATE N STATE	H Free and Brancasta Branc	11
CHICKLE	8 10 00 8 100 8 1000 8 1000 8 1000 8 1000 8 1000 8 1000 8 1000 8 10000	10000 50100 1000 1000 1000 1000	100				C C C C C C C C C C C C C C C C C C C	
								. A
		Factor from Dari Inas - Talifi Dagi tan - T	-	ie u Geografie		n di sa	f Innet sent fit have by	Tel .
		factor internet		E al Faired ( Alt Insel ( Alt	ar Chaily saw	a d 7 200 generation generation generation generation generation	i haataan Taan y	11
		Tony in Not in Till Ny in Till Ny in Ta		E al - Folio a (Alt Insel Alt Insel (Alt Insel (A	ar Chair ann	nd a T Balton again an d' 200 Jacobia Station Salar Ling	f familiant filmen	14
	-	fore in Barlan [10] Bartan [10] Bartan [10] Lin Mar		et al 	All Charles and Conservation	and <sup>1</sup> Nation again <sup>2</sup> Station again <sup>2</sup> Station <sup>2</sup>	i haalaan fi haa	14
	-	factor for Not the Table for the Table for Line State		10 al 20 -	All Products and	r J 7 Nation again 477,200 100 100 100 100 100 100 100	d Annual Annual An Annual — An Annual — An Annual — An Annual — An	TE
	Transfer Contraction	From the Bart New [ 107] Bart New [ 107] Bart New [ 107] Bart	10000000000000000000000000000000000000	20 dl 20 dl dose 20 dl dose	ar Chails age distance and the second and t	nd 4 7 Barto quat diana na angen contrati fin fin fin fin fin fin fin fin fin	d Annual server for Normer — All	16
		Frank Son Bayl Son Total Bay Son Bayl Bayl Bayl Bayl Bayl Bayl Bayl Bayl		20 33 20 7 300 m 20 7 300 m 20 7 30 0 m 10 10 10 0 m 10 10 10 0 m 10 10 10 0 m 10 10 10 0 m 10 0	10 Table and 10 Table 10 - 10 10 Table 10 - 10 10 Table 10 - 10 10 Table 10 10	4 47 204 4 47 204 4 48 49 494 1 4 49 494 1 4 49 1 14 1 19 1	f familyers: fil None al	16
	Total Total Total Total Total Total Total	France Trees Read Trees Total Total Trees Total Total		Li is Alter and a set of the set and a set of the set of the set of the set and a set of the set of the set of the set and a set of the se	All Charles ages All Charles ages All Charles All Char	nul d T Barro qua d das arbs gass St St C 1 (1) (1) (1) (1) (1) (1) (1) (1	i lanst ope fi hoos i j	16
		Frank Stee Real Sec. 2017 Bar Sec. 1 E 20 E 20 E 20 E 20 E 20 E 20 E 20 E 20	2010 2022 202 F	C di C di biorne C di Biorne C di Biorne C di Consel C di C di Consel C di di di Consel C di C di di Consel	at Charles uner Contraster Statistics S	T Berns quar an of 200 an of 200 and and and to Model 10 10 10 10 10 10 10 10 10 10	i finni prot fi finn	It
		France Sime Seaf Sea Tarit Bare Nac Linit State Manual Man	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	10 23 10 20 20 20 10 20 20 10 20 20 10 20 10 10 20 10 20 10 10	ari Chadi saari Jihi Sandi Saari Aran Diata Sandi Arian Sandi Sand	nal d T Backs Sant and T Dist para and T Dist and T Dist bit 1 S 1 S 1 S 1 S 1 S 1 S 1 S 1 S	i haaran filma	It
	Toma + Toma Ham	France Stee Start Team (1977) Start Team (1977) Start Team (1977) Start Team (1977) Start Team (1977) Start Team (1977) Start Team (1977)	A CONTRACTOR OF A CONTRACTOR OF A CONTRACTOR OF A CONTRACTOR A CONTRAC	20 23 24 2 200 m 24 2 200 m 20 200 m	All Clouds user All Clouds user and Clouds and angeing Decade 100 10000 100 1000 100 100 100 10		f Basel and ff Basel - g	
		France Line Seat Sea Line Sea Line Sea Line Sea Line Seat Seat Seat Seat Seat Seat Seat Seat		2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	401 Table super 100 Ta		i Roost ayar fi Kuus	

■ Harmonic Display Function Harmonic data measured by the 3169-20/21 and 3166 can be displayed in various ways

#### Harmonic Time Series Display

While displaying a time series graph, select the harmonic item for the vertical axis to display a time series graph of harmonics.

#### **Convenient Functions**

 Up to 32 graphs can be displayed simultaneously using 2-axes display.

For one circuit measurement, up to 32 orders can be graphed. Using multiple instruments, time series of harmonics can be easily compared.

(2) Any desired chronological detail can be easily confirmed using the cursors on the graph.

#### Harmonic List Display

 Displays harmonic data for the selected display item as a list.



#### Harmonic Graph Display

Displays harmonic data for the selected display item as a bar graph.



#### Harmonic Waveform Display

 Displays the voltage and current waveforms upon which harmonic data is based.

harmonics!

Simultaneously display multiple

orders to confirm changes in

Simultaneously display data from multiple instruments to confirm

concurrent series of harmonics!



#### Settings Display Function

When you select a data name to be load, the measuring instrument model and setting conditions at measurement time are displayed. Measurement data and measurement conditions can be managed at the same time.

#### Print Function

Reports and screen copies of the displayed screen can be easily printed.

Convenient Functions

- (1) Printing results can be confirmed by print preview.
- (2) When creating a report, screen data can be copied and pasted into a commercial word processor program.

Personane EFTANCION Personane Venian B Proster Venian Notes of childry Values of childry Values of childry Values of childry	2) Define Define Verific Define Define
Personale Hotel Longe Versien Ervetter Notes of childry Values (under Values (under Values (under Values (under Values (under	Sertine THE Verific Des Traw
Model surger Version Erventer Norter of cristin Values count Values count	1160 Weillon 1100 1100
Versee El nortes Mortes Nortes s'ictualle Voltace caret Voltace caret	DUI 1704
Notes of citodity Notes of citodity Volume covert	1734
Number of children Volfage covert V7 IPTC range	1.00
Voltage covert VT IPTC range	
VT IPTO range	THEY
	1.00
Clarent seren	Deckel 7 1004 Ceckel 21 1004
Browling house party and ed	CHILD IN THE SPECE & LINE
Sanging	PL .
PLL and plat	U
Weatoon new! Inc They are p	1010
Housewater, whereas	5 Mayle
Measurement stat, time	8/10/2XJ 16/X180



#### 9625 Specifications

#### General Specifications

Supported instrument models Operating environment : 3169-20, 3169-21 and 3166(CLAMP ON POWER HITESTERs) Computer: PC-AT compatible (DOS/V machine) CPU: Pentium 200 MHz or higher Memory: 128 MB or more (recommended) Hard disk: 128 MB or more free space Display: XGA (1024×768) or higher Disc device: CD-ROM drive (for installation) Operating system: Windows 2000, XP, 7 (English edition)



: One CD-R disc

### Functional Specifications \_\_\_\_\_

[Data/Settii	ig Load/Save i unctions]			
	Loading data /Setting	File extension	Data format	Data contents
	Data file	CSV	csv	Instantaneous value, average value, maximum value, minimum value, integrated value, demand value, harmonic
3169-20/21	Waveform data file	WUI	Binary	Instantaneous waveform
	Short-interval data file	BIN	Binary	Instantaneous values
	Integrated measurement data file	ITG	CSV	Instantaneous value, integrated value
	Demand measurement data file	DEM	CSV	Instantaneous value, maximum value, minimum value, demand value
3166	Harmonic measurement data file	HRM	CSV	Instantaneous value, average value, maximum value
	Waveform data file	WUI	Binary	Instantaneous waveform
	Setting file	SET	-	
9625	Combined file	DAT	Binary	

	Saved data /Setting	File extension	Data format	
9625	Combined file	DAT	Binary	

Maximum data capacity	: Up to 528 MB per data set (total composite data up to 1.5 GB)		
[Time Series Graph Display Function]			
Graph display item	<ul> <li>Voltage, current, active power, reactive power, apparent power, power factor, frequency, Integrated value(active power, reactive power), demand, harmonic (level, content ratio, phase angle, total value, THD)</li> </ul>	Reference value setting : Graph type selection : Graph line type & color :	Display set standard value Line, bar, 2-axes and 3-dimensional Line type and display color can be set for each data set.
Y-axis upper/lower limit setting Interval setting	<ul> <li>The display position (upper and lower display limits) of the vertical (Y) axis of a graph can be set by scroll bar or by specifying values.</li> <li>Select each cycle, or 0.1, 0.2, 0.5, 1, 2, 5, 10, 15 or 30 sec.; 1, 2, 5, 10, 15 or 30 min.; or 1, 2, 3, 4, 6, 8 or 12 h; or 1 day</li> </ul>	setting Stacked bar graph : display	and marker display is possible Up to 16 types of data series (demand value, demand quantity) can be displayed in an overlay graph
Display period range setting	: An optional analysis period can be specified from the overall measurement data period (1) Analysis start date and time (YMD, HMS) is specified numerically (2) Analysis stop date and time (YMD, HMS) is specified numerically Display of measurement data period (measurement start and stop date and time)	Cursor measurement : Data display units setting :	Measurement values can be displayed by the cursor Engineering units (m, k, M, G, etc.) can be selected

[Summary Display Function] Display item selectior	: Select the items to display in the summary	[Copy Function] Copies to the clipboard	: Each display can be copied to the clipboard
Daily, weekly and monthly report display Load factor calculation	: Displays a report for the specified daily weekly or monthly period : Calculates the load factor and demand factor as a daily, weekly	[Print Function] Printing a displayed time series graph	: Previews and prints the contents displayed on a time series graph
display Independent time range totalizing	or monthly report, and displays the results Specify up to four time ranges and totalize data for each time range independently	Printing a displayed summary Printing a barmonic	: Previews and prints the contents displayed in a summary
CO <sub>2</sub> conversion display	: Display the integrated active power (kWh) in CO <sub>2</sub> according to the conversion rate.	display Printing the settings	spreadsheet : Previews and prints the contents displayed in the settings
[Harmonic Display Function]		Comment entry Printing support	: Text comments can be entered in any printout Any color or monochrome printing supported by the operating
Waveform display List display Graph display	<ul> <li>Displays waveform data for a specified time</li> <li>Displays a list of harmonic data for a specified time</li> <li>Display a bar graph of barmonic data for a specified time</li> </ul>	[Display Language]	system
Cursor measurement	: Displays the value at the cursor with waveform and graph displays	[CSV Format	, English
[Setting Display Function] Setting display	Displays a list of the setting conditions	Conversion Function] _ Convertible screens	: Time-series graph; Summary; Daily,Weekly and Monthly Report: Harmonic Waveform
5 · · · · · · · · · · · · · · · · · · ·	Loads setting conditions from a data file ( <b>3169-20/21</b> ) Loads setting conditions from a settings file ( <b>3166</b> )		

#### ■ 3169-20/21 Specifications

#### Basic Specifications

#### Single-phase 2-wire, single-phase 3-wire, three-phase 3-wire three-phase 4-wire systems (50/60 Hz) $\,$ Measurement line type : Number of systems that can be measured (for systems that share Single-phase: 1P2W ..... 1P3W..... Three-phase: 3P3W2M (measures the voltage and current for two lines)..... the same voltage) 3P3W3M (measures the voltage and current for all three lines) $\ . \ .$ 3P4W (measures the voltage and current for three lines). . . . . . Voltage, current, active power, reactive power, apparent power power factor, integrated value, frequency, harmonics For the voltage, current, and active power ranges, see the range Item Measurement range configuration tables on page 2. Simultaneous digital sampling of voltage and current, PLL sy Measurement method Simultaneous digital samping or rotage or a fixed clock (50/60 Hz) Voltage: Isolated input Current: Isolated input using a clamp-on sensor Within 5 to 110% of the range Voltage and current: Within 0.4 to 130% of the range Input methods Effective measurement area Total display area (zero is suppressed for less than 0.4%) Power: Within 0 to 130% of the range (zero is suppressed when the voltage or currer Harmonic level: Within 0 to 130% of the range Display Range switching method Display update rate 5.7-inch LCD ( $320 \times 240$ dots), with backlight Manual (the current range can be set for each system) Approx. every 0.5 seconds t when using a PC card while acc g the internal memory, or when performing RS $2.0 \text{ M}\Omega \pm 10\%$ (differential input) Input resistance (50/60 Hz) Maximum input Voltage: Current: 200 k $\Omega \pm 10\%$ (unreferred input) Voltage input: 780 Vrms AC, peak value: 1103 V Current input: 1.7 Vrms AC, peak value: 1105 V Voltage input terminals: 600 Vrms AC (50/60 Hz) Maximum rated voltage to earth Crest factor Voltage: Less than 2 (for full-scale input) Less than 4 (for full-scale input. However, less than 2 for the 500 A, Current: Internal memory capacity : 1MB

#### Measurement Specifications

[Voltage/current measurement] _		[Frequency measurement] _		
Measurement method :	True RMS method	Measurement range :	40.000 to 70.000 Hz	
Measurement display :	Measurement of three voltage lines and 3 or 4 current lines is possible	Input area for :	Within 10 to 110% of the range	(for sine wave input)
	when using three-phase 3-wire and three-phase 4-wire systems	guaranteed accuracy		
		Measurement source :	Voltage U1	
[Active power measurement]				
Measurement display :	For three-phase 3-wire (the 3P3W3M setting), refer to the display for	[Integrated measurement] _		
	phase power values.	Measurement range :	Active power : 0.00000 mW	h to 99999.9 GWh consumption
Polarity display :	For consumption: no symbol, for regeneration: "-"		-0.00000 mW	h to -99999.9 GWh regeneration
			Reactive power: 0.00000 mva	arh to 99999.9 Gvarh lag
[Reactive power measurement] .			-0.00000 mva	arh to -999999.9 Gvarh lead
Using the reactive :	ON: Measures the reactive power directly using the reactive power	Measurement display :	Active power : Displays con	sumption and regeneration separately
power measurement	measurement method		Reactive power : Displays lag	and lead separately
method	OFF: Calculates the reactive power from the measurement values for			
	voltage, current, and active power	[Harmonic measurement] _	D	
Polarity display :	For lag phase (LAG : current is slower than voltage): no symbol	Measurement range :	Basic wave frequency: 45 to 66	HZ
	For lead phase (LEAD: current is faster than voltage) : "-"	Measurement method	PLL synchronization	
	(Reactive power measurement method "ON")	Window width	Op to the 40th order	128
[Annorant neuror measurement]		Window type	A single cycle (number of data	points analyzed: 128 points)
[Apparent power measurement] .	Na nalazity	Analysis rate	1/16 avalas	
Polarity display	No polarity	Itom for analysis	Harmonic level:	The voltage current or power level for
[Dowor factor measurement]		item for analysis .	Harmonic level.	each harmonic order
Moseuromont range	-1,0000 (lead) to 0,0000 to +1,0000 (lag)		Harmonic content percentage:	The voltage current or power
Polarity display	For lag phase. (LAG: current is slower than voltage) no symbol		marmonie content percentage.	content percentage for each harmonic order
i olanty display	For lead phase (LEAD: current is faster than voltage) .: "-"		Harmonic phase angle:	The voltage current or power phase
	· · · · · · · · · · · · · · · · · · ·			angle for each harmonic order
[Frequency measurement]		:	Total value:	The total value for voltage, current, or
Measurement range :	40.000 to 70.000 Hz			power up to the 40th harmonic order
Input area for	Within 10 to 110% of the range (for sine wave input)	:	Total harmonic distortion factor	For voltage or current
guaranteed accuracy				(THD-F or THD-R)
Measurement source :	Voltage U1			
	-			

#### Display Specifications

, and	Instantaneous value : display	Voltage, current, active power, reactive power, apparent power, power factor, frequency, average voltage, average current, (average
. 4 systems . 2 systems . 2 systems	Average value display :	values are for each system) Voltage, current, active power, reactive power, apparent power, power factor, frequency, average voltage, average current * The average value from the beginning of time series measurement until the present.
. 1 system . 1 system	Maximum/minimum : value display	Voltage, current, active power, reactive power, apparent power, power factor, frequency
. 1 system r lines) er,	Integrate display	* The maximum/minimum value from the beginning of time series measurement until the present. Integrated value Active power (consumption/regeneration)
ge ynchronization	Demand volume display : (Integrated value within the specified interval)	Reactive power (lag/lead) * The total integrated value from the beginning of time series measurement. Integrated value Active power volume (consumption/regeneration) Reactive power volume (lag/lead) * The integrate value within each secified interval (latest value).
	Demand value display : (average value within the specified interval)	Active power (consumption), reactive power (lag), power factor *The demand value within each specified interval (previous value).
nt is zero)	Maximum demand value display : (average value within the maximum specified interval)	The maximum demand value since the beginning of time series measurement and the time and date it occurred.
	Harmonics list :	List of the items measured for the specified harmonic (numerical value).
S-232C communications)	Harmonics graph :	(including the total value and total harmonic distortion factor (THD-F/THD-R)) Bar graph or vector diagram of the items measured for the specified harmonic. (curver measurement magnification undate with a linear/I OG axis election function)
	Waveform display :	Voltage and current waveforms (with a magnification update function)
	Measurement value : enlargement display	Select and enlarge up to 5 items from the instantaneous value display.
, 1 kA, and 5 kA ranges)		

#### **Setting Specifications**

[Setting contents]					
Measurement line settings :	1P2W, 1P3W, 3P3W2M, 3P3W3M, 3P4W, 3P4W4I				
Clamp-on sensor settings :	9694, 9660, 9661, CT9667(Choose the "9667" setting when using the				
	CT9667.), 9669, 9695-02 and 9695-03 (* A different sensor can be set				
	for each system.)				
VT (PT) and CT ratio settings :	0.01 to 9999.99 (* A different CT ratio can be set for each system.)				
Measurement start method :	Manual or time (year, month, day, hour, minute)				
Measurement stop method :	Manual, time, or timer (1 seconds to 8784 hours)				
Output Interval :	Standard or fast (*Maximum measurement period: 1 year)				
	Standard interval: 1, 2, 5, 10, 15, or 30 seconds, or 1, 2, 5, 10, 15, 30,				
	or 60 minutes				
	Fast interval: A single waveform, or 0.1, 0.2, or 0.5 seconds				
Data output destination :	PC card, internal memory, or printer				
File name :	Automatically attached, or set the desired name				
	(up to 8 alphanumeric characters)				
Display averaging circuit :	OFF, 2, 5, 10, 20 times (for movement averaging)				
Screen copy destination :	PC card, internal memory, or printer				
Display language settings :	Japanese, English, German, French, Italian, Chinese (Simple, Trad),				
	Spanish, Korean				
Other settings :	Reactive power measurement method selection, harmonic distortion				
	selection, order display selection, backlight settings, ID settings,				
	clock settings, etc.				
(File an entitie and					
[File operations]					
Copy life :	Copies files from the internal memory to the PC card.				
Doloto filo	Loads/Saves the file(s) selected from the internal memory or PC card.				
Format	Deletes the file(s) from the PC card.				
Storage format	Initializes the PC card or internal memory.				
otorage ionnat :	Measurement data: CSV format				
	(omary format when using the fast interval setting)				
	waveform data: Binary format				
	Screen data: BMP format				
	Settings data: CSV format				

#### External Interface Specifications \_\_\_\_\_

[D/A output]				
(3169-21 only)				
Number of output channels :	4 channels			
Output items :	For instantaneous values:	Voltage, current, average voltage, average current, Active power, reactive power, apparent power, power factor, frequency		
	For Integrated value:	Active power (consumption/regeneration) or reactive power (lag/lead)		
	For harmonics:	Each harmonic order (level, content percentage, and phase angle), total value, THD-F/THD-R		
Output level :	±5V DC/f.s.			
Resolution :	Polarity + 11 bits			
Output accuracy :	Measurement accuracy ±0	0.2% f.s.		
Temperature characteristic :	Less than ±0.02% f.s./°C			
Output resistance	100Ω ±5%			
Output update rate :	For each cycle of measurement input (when a measurement item other than harmon			
	For every 16 cycles of measurement input (when harmonics is set as the measurement item			
[PC card]				
	Slot:	1 × PC Card Standard-compliant Type II		
	Card type:	Flash ATA card		
	Compatible memory capa	city: Up to 528 MB		
	Storage content:	Settings data, measurement data, screen data		
[DC 0200]				
[R3-2320]	Printer or PC connected to	an RS 232C interface		
•	Compliance:	FIA RS 232C compliant		
	Transfer method:	Asynchronous communication method		
	Transfer method.	full duplox		
	Roud rate:	2400 0600 10200 28400 bpc		
	Elew central and delimiter cettings possible			
	Flow control and deminiter settings possible			
[External I/O]				
Control input	Start/stop control for time	series measurement data storage		
Control output	I OW level is output durin	ing time series measurement		
Control signal lovel	A 0/5 V logic signal or a s	hort-circuit/release contact signal		
Solution signal level	rors v togic signal of a short-circuit/release contact signal			

[Data output item]	
Instantaneous values :	Voltage, current, active power, reactive power, apparent power,
	power factor, frequency, average voltage, average current, (average
	values are for each system)
	* The instantaneous value for interval output.
Average value :	Voltage, current, active power, reactive power, apparent power,
	power factor, frequency, average voltage, average current, (average
	values are for each system)
	* The average value for each interval.
Maximum/minimum value :	Voltage, current, active power, reactive power, apparent power,
	power factor, frequency
	* The maximum/minimum value for each interval (no event details provided).
Integrated value :	Active power (consumption/regeneration)
	Reactive power (lag/lead)
	* The total value since the beginning of time series measurement, and the power volume for each interval.
Demand value :	Active power (consumption), reactive power (lag), power factor
	* The value for each interval.
Maximum demand value :	The maximum demand value since the beginning of time series
	measurement and the time and date it occurred.
Harmonic :	Each harmonic order (level, content percentage, and phase angle),
	total value, instantaneous value for THD-F/THD-R
:	Each harmonic order (level, content percentage, and phase angle),
	total value, average value for THD-F/THD-R for each interval
:	Each harmonic order (level, content percentage, and phase angle),
	total value, maximum/minimum value for THD-F/THD-R within
	each interval
	(no event data provided)
Waveform :	Waveform (Voltage or current)
Status information :	Exceeds the voltage/current crest factor, PLL unlock, power failure,
	exceeds the display limit
[Duint items]	
[Print items]	Distant de la desta de la desta content inter (de la dista dista de la desta de la desta de la desta de la dest
Numerical values	rinns the data selected as the data output item (during time series
Wayoform	Herd copy of the corean (printing of each interval not evailable)
waveloini	mand copy of the screen (printing of each interval not available)

## Formulae

Voltage	$U = \sqrt{\frac{1}{M} \sum_{n=1}^{M-1} (Us)^2}$	U: Inter-line voltage
č	MI S=0	M. Number of accorded
	1 <u>1</u> <u>M-1</u> 2	M: Number of samples
Current	$I = V \frac{1}{M} \sum_{s=0}^{\infty} (Is)^{s}$	s : Sample count
	112 3-0	m: 128 samples per cycle
Active	$P = \frac{1}{\Sigma} \sum_{i=1}^{M-1} (II_e \times I_e)$	
Power	$I = M \sum_{S=0}^{2} (CS \times IS)$	

#### Measurement is also possible using the reactive power measurement method

In addition to conventional calculation methods that search for reactive power using voltage, current, and active power, you can select the reactive power measurement method, which derives reactive power directly from voltage and current values, just as with the reactive power volume measurement method used in large-volume power consumers.

When using the reactive power measurement method:

Reactive	$O = \frac{1}{2} \sum_{n=1}^{M-1} \left[ u_{n+1} \left( u_{n+1} \right) \right]$	Derives reactive power directly from
power	$Q = \overline{M} \sum_{S=0}^{2} \left\{ US \times I(S + \frac{1}{4}) \right\}$	voltage and current values, just as with
Annorant		the measurement of active power.
nower	$S = \sqrt{P^2 + Q^2}$	(The same measurement principle is
Poner		the same as that used to determine
Power	$PF = -\frac{P}{P}$	reactive power by large-volume power
Tactor	$\sqrt{P^2+Q^2}$	consumers.)

When not using the reactive power measurement method:

Reactive power	$Q = \sqrt{S^2 P^2}$	Calculates reactive power after cal- culating the apparent power using the voltage current and RMS values
power	$S = U \times I$	voltago, current, and Rivis values.
Power factor	$PF = \frac{P}{S}$	

#### General Specifications

Operating environment : Operating temperature :	Indoors, up to 2000m (78.74ft) ASL 0 to 40°C, 80% RH or less (non-condensating)	Conforming standards :	Safety EN61010
and humidity	-10 to 50°C 80% RH or less (non-condensating)		Pollution degree 2, measurement category III (anticipated transient overvoltage 6000V)
and humidity	To to 50 C, 00% KIT of less (non condensating)	:	EMC
Withstand voltage :	5.55 kVrms AC: Between the voltage input terminal and the <b>3169</b>		EN61326
(50/60 HZ for 15 sec.)	3.32 kVrms AC: Between the voltage input terminal and the		EN01000-3-2, EN01000-3-3
	current input terminal/external interface terminal	Accessories :	voltage cord set L9438-53 (1) (1 cord each of black, red, yellow,
	2.3 kVrms AC: Between the power supply and the <b>3169</b> casing		and blue), voltage cord (1), input cord label (1), operating manuals (2) (Advanced edition and Quick Start Guide) CD P (1) (PS 232C)
	terminal/external interface terminal		interface operating manuals and CSV conversion Software),
Power supply voltage rating :	100 to 240 V AC, 50/60 Hz		connection cable 9441 (1) (for the 3169-21 only)
Maximum rated power :	30 VA		
Dimensions and weight :	Approx.210(8.27")W × 160(6.30") H × 60D(2.36") mm (excluding		
	protrusions), Approx 1.2 kg( $42.3$ or ) ( <b>2160</b> -20, <b>2160</b> 21)		
	Approx.1.2 kg(42.502.) (3103-20, 3103-21)		

#### Measurement accuracy (Guaranteed accuracy period : 1 year)

Voltage	Current/active power	
±0.2%rdg.±0.1%f.s.	$\pm 0.2\%$ rdg. $\pm 0.1\%$ f.s. + clamp-on sensor accuracy	

guaranteed accuracy Fundamental waveform range for : 45 to 66 Hz

guaranteed accuracy Display area for guaranteed accuracy : Effective measurement area

Current rang	9694	9695-02	9660, 9695-03	9661	9669	CT9667	Reference: Accuracy of the CLAMP ON SENSORE
0.5A	±0.5%rdg.±0.3%f.s.	±0.5%rdg.±2.1%f.s	-	-	-	-	9694,9695-02, 9695-03, 9660, 9661, 9667, and 9669
1A	±0.5%rdg.±0.2%f.s.	±0.5%rdg.±1.1%f.s	-	-	-	-	• <b>9694</b> (rated for 5 A) : ±0.3%rdg.±0.02%f.s.
5A	±0.5%rdg.±0.12%f.s.	±0.5%rdg.±0.3%f.s	±0.5%rdg.±0.5%f.s.	±0.5%rdg.±1.1%f.s.	-	-	• 9695-02 (rated for 50 A) : ±0.3%rdg.±0.02%f.s.
10A	-	±0.5%rdg.±0.2%f.s	±0.5%rdg.±0.3%f.s.	±0.5%rdg.±0.6%f.s.	-	-	<ul> <li>9695-03 (rated for 100 A): ±0.5%rdg.±0.02%f.s.</li> <li>9660 (rated for 100 A) : ±0.3%rdg ±0.02%f s</li> </ul>
50A	-	±0.5%rdg.±0.12%f.s.	±0.5%rdg.±0.14%f.s.	±0.5%rdg.±0.2%f.s.	-	-	• <b>9661</b> (rated for 500 A) : ±0.3%rdg.±0.01%f.s.
100A	-	-	±0.5%rdg.±0.12%f.s.	±0.5%rdg.±0.15%f.s	±1.2%rdg.±0.2%f.s.	-	• <b>9669</b> (rated for 1000 A) : ±1.0%rdg.±0.01%f.s.
200A	-	-	-	-	±1.2%rdg.±0.15%f.s.	-	• <b>CT9667</b> (rated for 5000 A) : ±2.0%rdg.±0.3%f.s.
500A	-	-	-	±0.5%rdg.±0.11%f.s.	-	$\pm 2.2\%$ rdg. $\pm 0.4\%$ f.s.	(500 A range: For 50 to 500 A input)
1000A	-	-	-	-	±1.2%rdg.±0.11%f.s.	-	(5000 A range: For 500 to 5000 A input)
5000A	-	-	-	-	-	±2.2%rdg.±0.4%f.s.	* f.s. is the sensor's rated primary current value.
Note: The table of accuracy for different clamp-on sensor combinations indicates the measurement accuracy for each current range of the <b>3169-</b> 20/21. (The accuracy for each clamp-on sensor is converted and displayed according to the <b>3169-</b> 20/21 current measurement range.)							
Apparent power a	accuracy : ±1 dgt. for	the calculation obtained	l from each measureme	ent value	Frequency characteri	stic : Fundamental v	vaveforms up to the 50th order $\pm 3\%$ f.s. + measurement

## Apparent power accuracy : ±1 dgt. for the calculation obtained from each measurement value Reactive power accuracy : When using the reactive power measurement method ±0.2% rdg. ±0.1% f.s. + clamp-on sensor accuracy

When not using the reactive power measurement method  $\pm 1$  dgt. for the calculation obtained from each measurement value

 Integration accuracy
 :
 ±1 dgt. for the calculation obtained from each measurement value

 Power factor accuracy
 :
 ±1 dgt. for the calculation obtained from each measurement value

 Power factor accuracy
 :
 ±1 dgt. for the calculation obtained from each measurement value

 Frequency accuracy
 :
 ±1 dgt. for the calculation obtained from each measurement value

Frequency characteristic	: Fundamental waveforms up to the 50th order $\pm 3\%$ f.s. + measurement accuracy (of a 45- to 66-Hz fundamental waveform)
Temperature characteristic	: Within $\pm 0.03\%$ f.s./°C
Effect of in-phase voltage	: Within ±0.2% f.s. (600 Vrms AC, 50/60 Hz, between voltage input terminal and case)
Effect of external magnetic field	: Within ±1.5% f.s. (in a magnetic field of 400 A/m rms AC, 50/60 Hz)
Power factor influence	: ±1.0% rdg. (45 to 66 Hz, power factor = 0.5, for effective power measurement)
Effect of reactive factor	$\pm 1.0\%$ rdg. (45 to 66 Hz, reactive factor = 0.5, when using the reactive power measurement method)
Real-time clock accuracy	$\pm 10 \text{ ppm} \pm 1 \text{ second} (23^{\circ}\text{C}) \text{ (within} \pm 1.9 \text{ sec/day} (23^{\circ}\text{C}))$

## Option Specifications

CLAMP ON SENSOR	9694	9660	9661	9669	
Appearance	Сот III 300V	Cord length: 3 m (9.84ft) CAT III 300V	Се сат ш 600V	Се се сот ш 600V	
Primary current rating	AC 5 A	AC 100 A	AC 500 A	AC 1000 A	
Output voltage	AC 10mV/A	AC 1mV/A	AC 1mV/A	AC 0.5mV/A	
Accuracy Amplitude (45 to 66 Hz)	billude (45 to 66 Hz) ±0.3%rdg.±0.02%f.s. ±0.3%rdg.±0.02%f.s. ±0.3%rdg.±0.01%f.s.		±1.0%rdg.±0.01%f.s.		
Phase (45 Hz to 5 kHz)	Within ±2°	Within ±1°	Within ±0.5°	Within ±1°	
Frequency characteristic	Within ±	Within ±2.0% at 40 Hz to 5 kHz (deviation from accuracy)			
Effect of external magnetic field	Equivale	nt to 0.1 A or less (with a magnetic field	Equivalent to 1 A or less (with a magnetic field of 400 A/m AC)		
Effect of conductor position		Within ±0.5%			
Maximum rated voltage to earth	300 V rms	300 V rms	600 V rms	600 V rms	
Maximum input (45 to 66 Hz)	50 A continuous	130 A continuous	550 A continuous	1000 A continuous	
Measurable conductor diameter	Less than \$\$\phi\$ 15 mm(0.59")	Less than $\phi$ 15 mm(0.59")	Less than $\phi$ 46 mm(1.81")	Less than φ 55 mm(2.17"), 80(3.15") × 20 (0.79")mm bus bar	
Dimensions and weight	46W(1.81") × 135H(5.31") × 21D(0.83") mm, 230g(9.9oz.)	46W(1.80") × 135H(5.31") × 21D(0.83") mm, 230g(9.9oz.)	77W(3.03") × 151H(5.94") × 42D(1.65")mm, 380g(12.7oz.)	99.5W(3.92") × 188H(7.40") × 42D(1.65") mm, 590g(20.8oz.)	

CLAMP ON SENSOR	CT9667	9695-02	9695-03
Appearance	C C C C C C C C C C C C C C C C C C C	СЕ САТ III 300V	Се сат II 3000
Primary current rating	AC 500 A, 5000A	AC 50 A	AC 100 A
Output voltage	AC 500 mV f.s.	AC 10 mV/A	AC 1 mV/A
Accuracy Amplitude (45 to 66 Hz)	$\pm 2.0\%$ rdg. $\pm 0.3\%$ f.s. (for input 10% or more of the renge)	±0.3%rdg.±0.02%f.s.	
Phase (45 Hz to 5 kHz)	Within ±1°	Within ±2°	Within ±1°
Frequency characteristic	Within ±3 dB at 10 Hz to 20 kHz (deviation from accuracy)	Within ±1.0% at 40 Hz to 5 kHz (deviation from accuracy)	
Effect of external magnetic field	1.5% f.s. or less. (in a magnetic field of 400 A/m AC, 50/60 Hz)	$Equivalent \ to \ 0.1 \ A \ or \ less \ ({\rm with \ a \ magnetic \ field \ of \ 400 \ A/m \ AC})$	
Effect of conductor position	Within ±3.0%	Within ±0.5%	
Maximum rated voltage to earth	1000 V rms (CAT III), 600Vrms (CAT IV)	300 V rms (insulated conductor)	
Maximum input (45 to 66 Hz)	10000 A continuous	60 A continuous	130 A continuous
Measurable conductor diameter	Less than \$\$\phi\$ 254 mm(10.0")	Less than \$\$ 15 mm(0.59")	
Dimensions and weight	Sensor thickness: φ13 mm (0.51") Circuit box: 35W(1.38") × 120H(4.74") × 34D(1.34") mm, 470g(16.6 oz.)	s: \$\operatorname{0.51}"\$)       \$50.5W(1.99") \times \$58H(2.28") \times \$18.7D(0.74")mm, \$50g(1.8oz.)\$         ne battery \times 2 (continuous operation max. 7 days)       \$0.5W(1.99") \times \$58H(2.28") \times \$18.7D(0.74")mm, \$50g(1.8oz.)\$         Option : CONNECTION CABLE \$219	
Power supply	LR06 alkaline battery × 2 (continuous operation max. 7 days) or AC ADAPTER 9445-02/9445-03(optional)		

## Option Specifications



(supplied with the voltage cord L9438-53 (1), and power cord (1))

### CLAMP ON POWER HITESTER

3169-21 (with D/A output) (supplied with the voltage cord L9438-53 (1), connection cable 9441 (1) and power cord (1))

Accessory Specifications

VOLTAGE CORD L9438-53 (1 cord each of black, red, yellow, and blue, cord length: 3 m(9.84ft)) CONNECTION CABLE 9441 (D/A output cable, supplied with the 3169-21)

Current and power cannot be measured using the CLAMP ON POWER HITESTER 3169-20/21 on its own. To perform current and power measurement, make sure you also purchase a CLAMF ON SENSOR (9694, 9660, 9661, CT9667, or 9669) (sold separately).

Use only PC Cards (9727, 9728) sold by HIOKI.

Compatibility and performance are not guaranteed for PC cards made by other manufacturers. You may be unable to read from or save data to such cards.

#### Combination examples

For single-phase 2-wire systems (one system)	:	3169-20 + 9660(100A) × 1 +9727(256MB)
For single-phase 3-wire systems	:	3169-20 + 9660(100A) × 2 +9727(256MB)
(one system/two single-phase 2-wire systems)		
For three-phase 3-wire systems (one system)	:	3169-20 + 9661(500A) × 2 +9727(256MB)
For three-phase 3-wire systems	:	3169-20 + 9661(500A) × 4 +9727(256MB)
(two systems/four single-phase 2-wire systems)		
For three-phase 4-wire systems (one system)	:	3169-20 + 9661(500A) × 3 +9727(256MB)



#### Headquarters :

HIOKI USA CORPORATION : TEL +1-609-409-9109 FAX +1-609-409-9108 http://www.hiokiusa.com / E-mail: hioki@hiokiusa.com

PC CARD 9727, 9728

#### MAGNETIC ADAPTER 9804-01, 02





Magnetic tip for use with the standard Voltage Cord L9438-53 (generally compatible with M6 pan screws)

Red and black adapters sold separately. Purchase the quantity and color

φ11mm

appropriate for your application. (Ex 3P3W - 3 adapters; 3P4W

CONNECTION CABLE 9219

For connection to the 9695-02, 9695-03



Cord length: 3 m(9.84ft)

## A soft type case for storing the 3169-20/21 and its accessories, such as the clamp-on sen-Approx. 445W(17.52") × 340H(13.39") × 150D(5.91") mm,

CLAMP ON SENSOR 9660 (AC 100A) CLAMP ON SENSOR 9661 (AC 500A) FLEXIBLE CLAMP ON SENSOR CT9667 (AC 5000A) CLAMP ON SENSOR 9669 (AC 1000A) CLAMP ON SENSOR 9694 (AC 5A) CLAMP ON SENSOR 9695-02 (AC 50A) CLAMP ON SENSOR 9695-03 (AC 100A) CONNECTION CABLE 9219 (for connection to the 9695-02, 9695-03) CLAMP ON ADAPTER 9290-10 (AC 1500A) CONNECTION CABLE 9440 (for external I/O) RS-232C CABLE 9612 (for connection to a PC) PRINTER 9442 AC ADAPTER 9443-02 (for the 9442, for Europe) RS-232C CABLE 9721 (for connection to the 9442) **RECORDING PAPER** 1196 (25 m(82ft)/10 rolls, for the 9442) CARRYING CASE 9720 POWER MEASUREMENT SUPPORT SOFTWARE 9625 PC CARD 256M 9727 PC CARD 512M 9728 MAGNETIC ADAPTER (1 red adapter) 9804-01 MAGNETIC ADAPTER (1 black adapter) 9804-02

Note: Company names and Product names appearing in this catalog are trademarks or registered trademarks of various companies

DISTRIBUTED BY

HIOKI (Shanghai) Sales & Trading Co., Ltd. : TEL +86-21-63910090 FAX +86-21-63910360 http://www.hioki.cn / E-mail: info@hioki.com.cn Beijing Office : TEL +86-10-84418761 FAX +86-10-84418763 / E-mail: info-bj@hioki.com.cn Guangzhou Office : TEL +86-20-38392673 FAX +86-20-38392679 / E-mail: info-gz@hioki.com.cn 
 Headquarters :
 Shenzhen Office : TEL +86-755-83038357

 81 Koizumi, Ueda, Nagano, 386-1192, Japan
 Shenzhen Office : TEL +86-755-83038357

 FEL +81-268-28-0562
 FAX +81-268-28-0568

 http://www.hioki.co.jp / E-mail: os-com@hioki.co.jp
 FAX +86-755-83039160 / E-mail: info-sz@hioki.

 HIDKI INDIA PRIVATE LIMITED :
 TEL +91-731-648081

 FAX +86-755-83039160 / E-mail: os-com@hioki.co.jp
 FAX +86-755-83039160 / E-mail: info-sz@hioki.
 Shenzhen Office : TEL +86-755-83038357 FAX +86-755-83039160 / E-mail: info-sz@hioki.com.cn HIOKI SINGAPORE PTE. LTD. : TEL +65-6634-7677 FAX +65-6634-7477 E-mail: info@hioki.com.sg

All information correct as of Aug. 27, 2012. All specifications are subject to change without notice.